


Position ID	Part number.	Replaces:	Description
0501	12009054		Induction hotplate
0502	12009053		Induction hotplate
0503	20000389		Glass ceramic hob top
0504	11033017		Case-bottom
0505	11033016		Fixture
0506	00636575		Cover
0507	00424665		Spring
0508	20000388		Frame
0509	12024441		Frame
0510	00634163		Clip
0511	10010298		Washer
0512	10008224		Screw
0513	11009412		Power module programmed
0513	11029160		Power module not programmed
0514	11019163	11031383	PC board
0515	12016115		Fan
0516	10008080		Connection piece
0517	10011946		Connection piece
0518	10008081		Connection piece
0519	11033019		Operating module
0520	11008964		Fixture
0521	11033020		Connection piece
0522	10011947		Connection piece
0523	12028662		Cable harness
0524	12009077		Sensor-NTC
0525	12009068		Sensor-NTC
0597	00267971		Sealing strip

0598	00617227		Screw-set
0598	00636637		Screw
0598	00636638		Screw
0599	00618647		Lubricant
0599	00636639		Screw
0599	00636640		Screw
0599	00637156		Screw
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product








Position ID	Part number.	Replaces:	Description
0601	11032521		Control module programmed
0601	12025831		Control module not programmed
0602	00418283		Support
0603	12028138		Limiter-temperature
0605	12028663		Control module
0606	10005470		Control module
0607	00489194		Transformer
0609	10010202		Clip
0610	10008207		Ignition cable
0611	12024415		Ignition cable
0612	12026867		Cable harness
0614	12024414		Cable harness
0615	12026845		Cable harness
0616	12028077		Cable harness set
0617	12026925		Cable harness
0620	11032800		Cable harness
0621	12028509		Cable harness
0623	11032801		Cable harness
0623	12028082		Cable harness
0624	12028086		Adapter
0635	12028664		Cable harness
0636	12028665		Cable harness
0637	12028666		Cable harness
0638	12028667		Cable harness
0608	10008933		Clip
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product


8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product
0604	12031987		Connectivity module

Position ID	Part number.	Replaces:	Description
0301	10004490		Burner cap
0302	10004489		Burner cap
0303	10004493		Burner
0304	10004492		Burner
0305	10004495		Venturi nozzle
0306	10006471		Electrode
0308	10004498		Burner housing
0309	10004497		Burner housing
0311	10006793		Jet
0312	10006797		Jet
0313	12007259		Ignition device
0315	00687075		Tray
0316	12024446		Heat shield
0317	10006795		Jet
0307	10008211		Screw
0310	10004531		Screw
0314	00701902		Rail
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care

8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
0318	11034110		Trimplate
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product





Position ID	Part number.	Replaces:	Description
1004	00774617		36" Telescopic Rack
1005	00484628	00449757	Tray for Broiler Pan
1006	11013689		Grill tray
1007	10010207		Bracket
1008	12022200		Sensor
1001	00145306		Grill grid
1002	00637940		Grate Foot Replacement Kit
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product



Position ID	Part number.	Replaces:	Description
0701	00497756		Motor
0702	00489178		Bracket
0703	00494383		Pipe connection piece
0704	10007424		Lamp
0705	00709468		Heating element
0706	10010225		Nut
0708	10008183		Socket
0709	00627375		Temperature sensor
0710	00640401		Heating element
0711	20000143		Cover
0712	11032546		Support
0713	10011396		Bolt
0714	12028136		Adapter
0715	00706444		Cover
0716	00479238		Cover
0718	00687604		Plate
0719	00431908		Broil Element
0707	10010208		Washer
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care


8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product




Position ID	Part number.	Replaces:	Description
0901	20000155		Door-outer
0902	20000156		Door-inner
0903	10011927		Bolt
0905	10011397		Handle-cap shaped
0906	11032802		Handle-door
0907	10011397		Handle-cap shaped
0908	10010271		Plate
0909	10010274		Screw
0912	10011608		Screw
0910	10008228		Screw
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product



0199




Position ID	Part number.	Replaces:	Description
0101	00146136		Back wall panel
0102	23000092		Back panel
0103	00649417	00752161	Cover
0104	23000263		Panel side
0105	23000264		Panel side
0108	20000278		Panel
0107	00619081		Connection piece
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product
0106	10013545		Latch




Position ID	Part number.	Replaces:	Description
0401	11032438		Gas tap
0402	11032439		Gas tap
0403	11032972		Gas tap
0404	11032973		Gas tap
0410	00423093		Valve
0412	10003806		Valve
0414	00420807		Screw
0415	20000371		Manifold
0417	10009569		Bracket
0424	00754658		Regulator-pressure
0425	10010200		Adapter
0426	11032865		Gas tap
0427	10011592		Extension for inlet
0428	10011926		Cap
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool

8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product





Position ID	Part number.	Replaces:	Description
0803	10011167		Limiter-temperature
0804	00628372		Terminal
0805	00651285		Latch
0806	00618400		Switch-door
0807	00634163		Clip
0815	20000145		Seal-door
0830	00648862		Cable harness
0812	12028141		Cover
0814	00655554		Receiver
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
0808	12013593		Bolt
0809	10001186		Plate
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product

0811	10014059		Cover
0802	10020212		Fan motor
0801	10020211		Fan motor








Position ID	Part number.	Replaces:	Description
0201	12024418		Module-relay
0203	00617931		Display
0204	11032519		Bracket
0205	00609115		Switch
0206	11032495		Display module not programmed
0207	10010232		Encoder
0209	00687127		Light bar
0210	20000042	23000467	Support
0212	20000028		Panel-facia
0215	00418122		Ring
0216	10010231		Encoder
0217	10011598		Knob
0218	10008201		Ring
0219	10011924		Knob
0221	10010228		Ring
0222	10010230		Knob
0223	10011925		Knob
0224	12028661		Switch-selector
0225	00617886		Display
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent

8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
0213	10008212		Screw
0214	10008201		Ring
0206	12028837		Display module programmed
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product
0211	00623615		Nut
0220	12034239		Display-temperature




Position ID	Part number.	Replaces:	Description
0901	20000155		Door-outer
0902	20000156		Door-inner
0903	10011927		Bolt
0905	10011397		Handle-cap shaped
0906	11032802		Handle-door
0907	10011397		Handle-cap shaped
0908	10010271		Plate
0909	10010274		Screw
0912	10011608		Screw
0910	10008228		Screw
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product




Position ID	Part number.	Replaces:	Description
1004	00774617		36" Telescopic Rack
1005	00484628	00449757	Tray for Broiler Pan
1006	11013689		Grill tray
1007	10010207		Bracket
1008	12022200		Sensor
1001	00145306		Grill grid
1002	00637940		Grate Foot Replacement Kit
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product



0199




Position ID	Part number.	Replaces:	Description
0101	00146136		Back wall panel
0102	23000092		Back panel
0103	00649417	00752161	Cover
0104	23000263		Panel side
0105	23000264		Panel side
0108	20000278		Panel
0107	00619081		Connection piece
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product
0106	10013545		Latch




Position ID	Part number.	Replaces:	Description
0701	00497756		Motor
0702	00489178		Bracket
0703	00494383		Pipe connection piece
0704	10007424		Lamp
0705	00709468		Heating element
0706	10010225		Nut
0708	10008183		Socket
0709	00627375		Temperature sensor
0710	00640401		Heating element
0711	20000143		Cover
0712	11032546		Support
0713	10011396		Bolt
0714	12028136		Adapter
0715	00706444		Cover
0716	00479238		Cover
0718	00687604		Plate
0719	00431908		Broil Element
0707	10010208		Washer
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care

8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product




Position ID	Part number.	Replaces:	Description
0803	10011167		Limiter-temperature
0804	00628372		Terminal
0805	00651285		Latch
0806	00618400		Switch-door
0807	00634163		Clip
0815	20000145		Seal-door
0830	00648862		Cable harness
0812	12028141		Cover
0814	00655554		Receiver
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
0808	12013593		Bolt
0809	10001186		Plate
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product

0811	10014059		Cover
0802	10020212		Fan motor
0801	10020211		Fan motor




Position ID	Part number.	Replaces:	Description
0201	12024418		Module-relay
0203	00617931		Display
0204	11032519		Bracket
0205	00609115		Switch
0206	11032495		Display module not programmed
0207	10010232		Encoder
0209	00687127		Light bar
0210	20000042	23000467	Support
0212	20000028		Panel-facia
0215	00418122		Ring
0216	10010231		Encoder
0217	10011598		Knob
0218	10008201		Ring
0219	10011924		Knob
0221	10010228		Ring
0222	10010230		Knob
0223	10011925		Knob
0224	12028661		Switch-selector
0225	00617886		Display
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent

8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
0213	10008212		Screw
0214	10008201		Ring
0206	12028837		Display module programmed
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product
0211	00623615		Nut
0220	12034239		Display-temperature




Position ID	Part number.	Replaces:	Description
0401	11032438		Gas tap
0402	11032439		Gas tap
0403	11032972		Gas tap
0404	11032973		Gas tap
0410	00423093		Valve
0412	10003806		Valve
0414	00420807		Screw
0415	20000371		Manifold
0417	10009569		Bracket
0424	00754658		Regulator-pressure
0425	10010200		Adapter
0426	11032865		Gas tap
0427	10011592		Extension for inlet
0428	10011926		Cap
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool

8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product




Position ID	Part number.	Replaces:	Description
0301	10004490		Burner cap
0302	10004489		Burner cap
0303	10004493		Burner
0304	10004492		Burner
0305	10004495		Venturi nozzle
0306	10006471		Electrode
0308	10004498		Burner housing
0309	10004497		Burner housing
0311	10006793		Jet
0312	10006797		Jet
0313	12007259		Ignition device
0315	00687075		Tray
0316	12024446		Heat shield
0317	10006795		Jet
0307	10008211		Screw
0310	10004531		Screw
0314	00701902		Rail
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care

8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
0318	11034110		Trimplate
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product



Position ID	Part number.	Replaces:	Description
0501	12009054		Induction hotplate
0502	12009053		Induction hotplate
0503	20000389		Glass ceramic hob top
0504	11033017		Case-bottom
0505	11033016		Fixture
0506	00636575		Cover
0507	00424665		Spring
0508	20000388		Frame
0509	12024441		Frame
0510	00634163		Clip
0511	10010298		Washer
0512	10008224		Screw
0513	11009412		Power module programmed
0513	11029160		Power module not programmed
0514	11019163	11031383	PC board
0515	12016115		Fan
0516	10008080		Connection piece
0517	10011946		Connection piece
0518	10008081		Connection piece
0519	11033019		Operating module
0520	11008964		Fixture
0521	11033020		Connection piece
0522	10011947		Connection piece
0523	12028662		Cable harness
0524	12009077		Sensor-NTC
0525	12009068		Sensor-NTC
0597	00267971		Sealing strip

0598	00617227		Screw-set
0598	00636637		Screw
0598	00636638		Screw
0599	00618647		Lubricant
0599	00636639		Screw
0599	00636640		Screw
0599	00637156		Screw
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product



Position ID	Part number.	Replaces:	Description
0601	11032521		Control module programmed
0601	12025831		Control module not programmed
0602	00418283		Support
0603	12028138		Limiter-temperature
0605	12028663		Control module
0606	10005470		Control module
0607	00489194		Transformer
0609	10010202		Clip
0610	10008207		Ignition cable
0611	12024415		Ignition cable
0612	12026867		Cable harness
0614	12024414		Cable harness
0615	12026845		Cable harness
0616	12028077		Cable harness set
0617	12026925		Cable harness
0620	11032800		Cable harness
0621	12028509		Cable harness
0623	11032801		Cable harness
0623	12028082		Cable harness
0624	12028086		Adapter
0635	12028664		Cable harness
0636	12028665		Cable harness
0637	12028666		Cable harness
0638	12028667		Cable harness
0608	10008933		Clip
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product

8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product
0604	12031987		Connectivity module