






0396



Position ID	Part number.	Replaces:	Description
0301	10004490		Burner cap
0302	10004489		Burner cap
0303	10004493		Burner
0304	10004492		Burner
0305	10004495		Venturi nozzle
0306	10006471		Electrode
0308	10004498		Burner housing
0309	10004497		Burner housing
0311	10006793		Jet
0312	10006797		Jet
0313	12007259		Ignition device
0315	10006795		Jet
0316	11013687		Hob top
0317	10008221		Heat shield
8042	18037395		Installation instructions
0307	10008211		Screw
0310	10004531		Screw
0314	00701902		Rail




Position ID	Part number.	Replaces:	Description
1004	00774617		36" Telescopic Rack
1005	11013689		Grill tray
1006	00484628	00449757	Tray for Broiler Pan
1007	10010207		Bracket
1008	12022200		Sensor
8042	18037395		Installation instructions
1001	00145306		Grill grid
1002	00637940		Grate Foot Replacement Kit




Position ID	Part number.	Replaces:	Description
0803	10011167		Limiter-temperature
0804	00628372		Terminal
0805	00651285		Latch
0806	00618400		Switch-door
0807	10001186		Plate
0808	12013593		Bolt
0812	12028141		Cover
0815	20000145		Seal-door
0830	00648862		Cable harness
8042	18037395		Installation instructions
0814	00655554		Receiver
0809	10001351		Foot
0811	10014059		Cover
0802	10020212		Fan motor
0801	10020211		Fan motor





Position ID	Part number.	Replaces:	Description
8042	18037395		Installation instructions
0903	10010275		Screw
0905	10011397		Handle-cap shaped
0906	11032802		Handle-door
0907	10011397		Handle-cap shaped
0908	10010271		Plate
0909	10010274		Screw
0910	10008228		Screw
0911	11032545		Hinge
0912	00618862		Screw
0901	20000155		Door-outer
0902	20000156		Door-inner



Position ID	Part number.	Replaces:	Description
0601	11032521		Control module programmed
0601	12025831		Control module not programmed
0602	00418283		Support
0603	12028138		Limiter-temperature
0606	10005470		Control module
0607	00489194		Transformer
0609	10010202		Clip
0610	10008207		Ignition cable
0611	12024415		Ignition cable
0612	12026846		Cable harness
0613	12028510		Cable harness
0615	12026845		Cable harness
0616	12028077		Cable harness set
0617	12026925		Cable harness
0620	11032800		Cable harness
0621	12028509		Cable harness
0623	11032801		Cable harness
0623	12028082		Cable harness
0624	12028086		Adapter
8042	18037395		Installation instructions
0608	10008933		Clip
0604	12031987		Connectivity module




Position ID	Part number.	Replaces:	Description
0401	11032438		Gas tap
0402	11032439		Gas tap
0405	11032440		Gas tap
0406	11032441		Gas tap
0410	00423093		Valve
0412	10003806		Valve
0414	00420807		Screw
0415	00779007		Manifold
0416	20000140		Manifold
0417	10009569		Bracket
0422	10010270		Pipe connection piece
0423	11032864		Gas tap
0424	00754658		Regulator-pressure
0425	10010200		Adapter
0426	11032865		Gas tap
0427	10011592		Extension for inlet
8042	18037395		Installation instructions




Position ID	Part number.	Replaces:	Description
0502	10008228		Screw
0503	00634163		Clip
0506	00145749		Grill grid
0507	11030956		Heating element
0508	10008210		Screw
0509	11030067		Grill accessories
0510	11030015		Tray for Ceramic Briquettes (for PABRICKBKW)
0511	00098049		Salver
0512	12004405		Temperature sensor
0513	10008210		Screw
0514	00634165		Bracket
0515	10008210		Screw
0516	12026866		Cable harness
8042	18037395		Installation instructions
0504	00321402		Ring
0505	10008210		Screw




0199



Position ID	Part number.	Replaces:	Description
0101	00146136		Back wall panel
0102	23000092		Back panel
0103	00649417	00752161	Cover
0104	23000263		Panel side
0105	23000264		Panel side
0107	00619081		Connection piece
0108	20000278		Panel
8042	18037395		Installation instructions
0106	10013545		Latch



Position ID	Part number.	Replaces:	Description
0203	00617931		Display
0204	11032519		Bracket
0205	00609115		Switch
0206	11032495		Display module not programmed
0207	10010232		Encoder
0209	00687127		Light bar
0210	20000042	23000467	Support
0212	20000026		Panel-facia
0214	10008201		Ring
0215	00418122		Ring
0216	10010231		Encoder
0217	10011598		Knob
0218	10008199		Knob
0219	10008225		Knob
0221	10010228		Ring
0222	10010230		Knob
0223	10008226		Bracket
0224	00629049		Energy regulator
0225	00617886		Display
0230	12026865		Cable harness
8042	18037395		Installation instructions
0201	12024418		Module-relay
0213	10008212		Screw
0206	12028839		Display module programmed
0211	00623615		Nut
0220	12034239		Display-temperature



Position ID	Part number.	Replaces:	Description
0701	00497756		Motor
0702	00489178		Bracket
0703	00494383		Pipe connection piece
0704	10007424		Lamp
0705	00709468		Heating element
0706	10010225		Nut
0707	10010208		Washer
0708	10008183		Socket
0709	00627375		Temperature sensor
0710	00640401		Heating element
0711	20000143		Cover
0712	11032546		Support
0713	10011396		Bolt
0714	12028136		Adapter
0715	00706444		Cover
0716	00479238		Cover
0718	00687604		Plate
0719	00431908		Broil Element
8042	18037395		Installation instructions