






Position ID	Part number.	Replaces:	Description
0901	00497756		Motor
0902	00447402		Cover
0903	00494383		Pipe connection piece
0904	10007424		Lamp
0905	00709468		Heating element
0906	10010225		Nut
0908	00632039	10007567	Socket
0909	00627375		Temperature sensor
0910	00640401		Heating element
0912	00146140		Support
0913	10011396		Bolt
0915	00706444		Cover
0916	00479238		Cover
0918	00688243		Reflector
0919	00497632		Heating element
0920	10011798		Cable harness
0911	11030909		Cover
0999	12030862		Repair-set
0921	10020313		Cover





Position ID	Part number.	Replaces:	Description
1101	20000091		Door-outer
1102	20000092		Door-inner
1103	10010275		Screw
1104	10011398		Bracket
1105	10011397		Handle-cap shaped
1106	11033705		Handle-door
1107	10011397		Handle-cap shaped
1109	10010274		Screw
1111	11032539		Hinge
1110	10010274		Screw




Position ID	Part number.	Replaces:	Description
0501	12024441		Frame
0502	10008228		Screw
0503	00634163		Clip
0504	10010298		Washer
0505	10008224		Screw
0506	00145749		Grill grid
0507	11030956		Heating element
0508	10008210		Screw
0510	11030015		Tray for Ceramic Briquettes (for PABRICKBKW)
0511	00098049		Salver
0512	12004405		Temperature sensor
0513	10008210		Screw
0514	00634165		Bracket
0515	10008210		Screw
0516	12026866		Cable harness
0509	11030067		Grill accessories




Position ID	Part number.	Replaces:	Description
0601	00778241		Griddle
0602	12024437		Tray
0603	12028074		Heating element
0604	12024439		Retaining plate
0605	12024438		Insulating part
0606	12028085		Cable harness




Position ID	Part number.	Replaces:	Description
1201	20000063		Door-outer
1202	20000064		Door-inner
1203	10010275		Screw
1204	10011398		Bracket
1205	10011397		Handle-cap shaped
1206	11032089		Handle
1207	10011397		Handle-cap shaped
1208	10010271		Plate
1209	10010274		Screw
1210	10008228		Screw
1211	10011376		Hinge
1212	00618862		Screw



Position ID	Part number.	Replaces:	Description
1303	00774612		18" Telescopic Rack
1304	00774613		30" Telescopic Rack
1305	11013689		Grill tray
1306	00484628	00449757	Tray for Broiler Pan
1307	00666709		Tray for Broiler Pan
1308	00666710		Broiler Pan
1309	10010207		Bracket
1310	00753356		Sensor
1301	00145306		Grill grid
1302	00637940		Grate Foot Replacement Kit









Position ID	Part number.	Replaces:	Description
0401	11030914		Gas tap
0402	11030913		Gas tap
0403	11032796		Gas tap
0404	11032797		Gas tap
0410	00423093		Valve
0412	10003806		Valve
0413	10009155		Valve
0414	00420807		Screw
0415	20000265		Manifold
0417	10009569		Bracket
0424	00754658		Regulator-pressure
0425	10010200		Adapter
0426	11030960		Gas tap
0427	10010197		Bracket
0428	10011926		Cap




Position ID	Part number.	Replaces:	Description
1003	10011167		Limiter-temperature
1004	00628372		Terminal
1005	00651285		Latch
1006	00618400		Switch-door
1007	10001186		Plate
1008	10011170		Bolt
1011	12026847		Seal-door
1012	11030961		Seal-door
1030	00648862		Cable harness
1010	00649416		Hinge-plate
1009	10001351		Foot
1002	10020212		Fan motor
1001	10020211		Fan motor




0199




Position ID	Part number.	Replaces:	Description
0102	11031592		Back panel
0103	00649417	00752161	Cover
0104	20000372		Panel
0105	20000373		Panel side
0106	00719250		Panel side
0107	00771304		Front panel
0108	00623741		Screw
0101	00146135		Back wall panel





Position ID	Part number.	Replaces:	Description
0201	12024418		Module-relay
0202	12024417		Module-relay
0203	00617931		Display
0204	00618025		Display
0205	00609115		Switch
0206	11032495		Display module not programmed
0209	10010233		Encoder
0210	10010232		Encoder
0211	00719263	23000460	Support
0213	20000022		Panel-facia
0214	10008212		Screw
0215	10008201		Ring
0216	00418122		Ring
0217	10010231		Encoder
0218	10008199		Knob
0219	10008200		Knob
0221	10010229		Ring
0222	10010228		Ring
0223	10008226		Bracket
0224	00629049		Energy regulator
0225	00617886		Display
0227	10010230		Knob
0228	10008225		Knob
0229	10000773		Regulator-temperature
0231	10009568		Knob
0206	12028876		Display module programmed
0212	00623615		Nut



Position ID	Part number.	Replaces:	Description
0701	11032521		Control module programmed
0701	12025831		Control module not programmed
0702	00418283		Support
0703	12024477	12034882	Control module
0704	12028138		Limiter-temperature
0706	10005470		Control module
0707	00489194		Transformer
0709	10008933		Clip
0710	10010202		Clip
0711	12024415		Ignition cable
0712	12026867		Cable harness
0713	12026871		Cable harness
0715	12026845		Cable harness
0716	12028077		Cable harness set
0717	12026925		Cable harness
0718	12026869		Cable harness
0719	12026872		Cable harness
0720	12026870		Cable harness
0721	12024436		Cable harness
0722	10010201		Adapter
0723	12026868		Cable harness
0730	12026865		Cable harness
0724	10008207		Ignition cable
0708	12031987		Connectivity module




Position ID	Part number.	Replaces:	Description
0301	10004490		Burner cap
0302	10004489		Burner cap
0303	10004493		Burner
0304	10004492		Burner
0305	10004495		Venturi nozzle
0306	10006471		Electrode
0308	10004498		Burner housing
0309	10004497		Burner housing
0311	10006793		Jet
0312	10006797		Jet
0313	12007259		Ignition device
0315	00687075		Tray
0316	12024446		Heat shield
0307	10008211		Screw
0310	10004531		Screw
0314	00701902		Rail




Position ID	Part number.	Replaces:	Description
0803	12004406		Burner pipe
0804	10007424		Lamp
0805	00709469		Heating element
0809	00627375		Temperature sensor
0812	11030962		Guide
0813	10011396		Bolt
0818	00741560		Reflector
0819	00741559		Heating element




0199




Position ID	Part number.	Replaces:	Description
0102	11031592		Back panel
0103	00649417	00752161	Cover
0104	20000372		Panel
0105	20000373		Panel side
0106	00719250		Panel side
0107	00771304		Front panel
0108	00623741		Screw
0101	00146135		Back wall panel




Position ID	Part number.	Replaces:	Description
0201	12024418		Module-relay
0202	12024417		Module-relay
0203	00617931		Display
0204	00618025		Display
0205	00609115		Switch
0206	11032495		Display module not programmed
0209	10010233		Encoder
0210	10010232		Encoder
0211	00719263	23000460	Support
0213	20000022		Panel-facia
0214	10008212		Screw
0215	10008201		Ring
0216	00418122		Ring
0217	10010231		Encoder
0218	10008199		Knob
0219	10008200		Knob
0221	10010229		Ring
0222	10010228		Ring
0223	10008226		Bracket
0224	00629049		Energy regulator
0225	00617886		Display
0227	10010230		Knob
0228	10008225		Knob
0229	10000773		Regulator-temperature
0231	10009568		Knob
0206	12028876		Display module programmed
0212	00623615		Nut




Position ID	Part number.	Replaces:	Description
0301	10004490		Burner cap
0302	10004489		Burner cap
0303	10004493		Burner
0304	10004492		Burner
0305	10004495		Venturi nozzle
0306	10006471		Electrode
0308	10004498		Burner housing
0309	10004497		Burner housing
0311	10006793		Jet
0312	10006797		Jet
0313	12007259		Ignition device
0315	00687075		Tray
0316	12024446		Heat shield
0307	10008211		Screw
0310	10004531		Screw
0314	00701902		Rail




Position ID	Part number.	Replaces:	Description
0401	11030914		Gas tap
0402	11030913		Gas tap
0403	11032796		Gas tap
0404	11032797		Gas tap
0410	00423093		Valve
0412	10003806		Valve
0413	10009155		Valve
0414	00420807		Screw
0415	20000265		Manifold
0417	10009569		Bracket
0424	00754658		Regulator-pressure
0425	10010200		Adapter
0426	11030960		Gas tap
0427	10010197		Bracket
0428	10011926		Cap





Position ID	Part number.	Replaces:	Description
0501	12024441		Frame
0502	10008228		Screw
0503	00634163		Clip
0504	10010298		Washer
0505	10008224		Screw
0506	00145749		Grill grid
0507	11030956		Heating element
0508	10008210		Screw
0510	11030015		Tray for Ceramic Briquettes (for PABRICKBKW)
0511	00098049		Salver
0512	12004405		Temperature sensor
0513	10008210		Screw
0514	00634165		Bracket
0515	10008210		Screw
0516	12026866		Cable harness
0509	11030067		Grill accessories




Position ID	Part number.	Replaces:	Description
0601	00778241		Griddle
0602	12024437		Tray
0603	12028074		Heating element
0604	12024439		Retaining plate
0605	12024438		Insulating part
0606	12028085		Cable harness




Position ID	Part number.	Replaces:	Description
0701	11032521		Control module programmed
0701	12025831		Control module not programmed
0702	00418283		Support
0703	12024477	12034882	Control module
0704	12028138		Limiter-temperature
0706	10005470		Control module
0707	00489194		Transformer
0709	10008933		Clip
0710	10010202		Clip
0711	12024415		Ignition cable
0712	12026867		Cable harness
0713	12026871		Cable harness
0715	12026845		Cable harness
0716	12028077		Cable harness set
0717	12026925		Cable harness
0718	12026869		Cable harness
0719	12026872		Cable harness
0720	12026870		Cable harness
0721	12024436		Cable harness
0722	10010201		Adapter
0723	12026868		Cable harness
0730	12026865		Cable harness
0724	10008207		Ignition cable
0708	12031987		Connectivity module





Position ID	Part number.	Replaces:	Description
0803	12004406		Burner pipe
0804	10007424		Lamp
0805	00709469		Heating element
0809	00627375		Temperature sensor
0812	11030962		Guide
0813	10011396		Bolt
0818	00741560		Reflector
0819	00741559		Heating element





Position ID	Part number.	Replaces:	Description
0901	00497756		Motor
0902	00447402		Cover
0903	00494383		Pipe connection piece
0904	10007424		Lamp
0905	00709468		Heating element
0906	10010225		Nut
0908	00632039	10007567	Socket
0909	00627375		Temperature sensor
0910	00640401		Heating element
0912	00146140		Support
0913	10011396		Bolt
0915	00706444		Cover
0916	00479238		Cover
0918	00688243		Reflector
0919	00497632		Heating element
0920	10011798		Cable harness
0911	11030909		Cover
0999	12030862		Repair-set
0921	10020313		Cover




Position ID	Part number.	Replaces:	Description
1003	10011167		Limiter-temperature
1004	00628372		Terminal
1005	00651285		Latch
1006	00618400		Switch-door
1007	10001186		Plate
1008	10011170		Bolt
1011	12026847		Seal-door
1012	11030961		Seal-door
1030	00648862		Cable harness
1010	00649416		Hinge-plate
1009	10001351		Foot
1002	10020212		Fan motor
1001	10020211		Fan motor



Position ID	Part number.	Replaces:	Description
1101	20000091		Door-outer
1102	20000092		Door-inner
1103	10010275		Screw
1104	10011398		Bracket
1105	10011397		Handle-cap shaped
1106	11033705		Handle-door
1107	10011397		Handle-cap shaped
1109	10010274		Screw
1111	11032539		Hinge
1110	10010274		Screw



Position ID	Part number.	Replaces:	Description
1201	20000063		Door-outer
1202	20000064		Door-inner
1203	10010275		Screw
1204	10011398		Bracket
1205	10011397		Handle-cap shaped
1206	11032089		Handle
1207	10011397		Handle-cap shaped
1208	10010271		Plate
1209	10010274		Screw
1210	10008228		Screw
1211	10011376		Hinge
1212	00618862		Screw



Position ID	Part number.	Replaces:	Description
1303	00774612		18" Telescopic Rack
1304	00774613		30" Telescopic Rack
1305	11013689		Grill tray
1306	00484628	00449757	Tray for Broiler Pan
1307	00666709		Tray for Broiler Pan
1308	00666710		Broiler Pan
1309	10010207		Bracket
1310	00753356		Sensor
1301	00145306		Grill grid
1302	00637940		Grate Foot Replacement Kit