



<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0903	10011167		Limiter-temperature
0904	00628372		Terminal
0905	00651285		Latch
0906	00618400		Switch-door
0907	10001186		Plate
0908	12013593		Bolt
0909	10001351		Foot
0912	12028141		Cover
0915	12028710		Seal-door
0916	20000145		Seal-door
0930	00648862		Cable harness
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
0914	00655554		Receiver
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder

8025	00311964		Care product
0911	10014059		Cover
0901	10020211		Fan motor
0902	10020212		Fan motor
0999	12030965		Repair-set



<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0701	00497756		Motor
0702	00489178		Bracket
0704	10007424		Lamp
0705	00709469		Heating element
0706	10010225		Nut
0708	10008183		Socket
0709	00627375		Temperature sensor
0710	00750884		Heater-ring
0711	12028706		Cover
0712	11032546		Support
0713	10011396		Bolt
0714	12028136		Adapter
0715	00706442		Reflector
0716	00655581		Plate
0718	00708175		Plate
0719	11033032		Heating element
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care


0703	00494383		Pipe connection piece
0707	10010208		Washer
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product



<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0501	12009054		Induction hotplate
0502	12009053		Induction hotplate
0503	20000389		Glass ceramic hob top
0504	11033017		Case-bottom
0505	11033016		Fixture
0506	00636575		Cover
0507	00424665		Spring
0508	20000388		Frame
0509	12024441		Frame
0510	00634163		Clip
0511	10010298		Washer
0512	10008224		Screw
0513	11009412		Power module programmed
0513	11029160		Power module not programmed
0514	11019163	11031383	PC board
0515	12016115		Fan
0516	10008080		Connection piece
0517	10011946		Connection piece
0518	10008081		Connection piece
0519	11033019		Operating module
0520	11008964		Fixture
0521	11033020		Connection piece
0522	10011947		Connection piece
0523	12028662		Cable harness
0524	12009077		Sensor-NTC
0525	12009068		Sensor-NTC
0597	00267971		Sealing strip



0598	00617227		Screw-set
0598	00636637		Screw
0598	00636638		Screw
0599	00618647		Lubricant
0599	00636639		Screw
0599	00636640		Screw
0599	00637156		Screw
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product





<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0401	11032438		Gas tap
0402	11032439		Gas tap
0403	11032863		Gas tap
0404	11032862		Gas tap
0405	11033111		Gas tap
0406	11033112		Gas tap
0410	00423093		Valve
0412	10003806		Valve
0413	10009155		Valve
0414	00420807		Screw
0415	20000265		Manifold
0416	20000140		Manifold
0417	10009569		Bracket
0422	10010270		Pipe connection piece
0423	11033113		Gas tap
0424	00754658		Regulator-pressure
0425	10010200		Adapter
0426	11033031		Hose-inlet
0427	10011592		Extension for inlet
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent

8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product





<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0301	10004490		Burner cap
0302	10004489		Burner cap
0303	10004493		Burner
0304	10004492		Burner
0305	10004495		Venturi nozzle
0306	10006471		Electrode
0308	10004498		Burner housing
0309	10004497		Burner housing
0311	10006793		Jet
0312	10006797		Jet
0313	12007259		Ignition device
0315	00687135		Tray
0317	10006795		Jet
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
0307	10008211		Screw
0310	10004531		Screw
0314	00701902		Rail

8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product
0316	12034075		Heat shield






<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
1001	20000149		Door-outer
1002	20000150		Door-inner
1003	10011927		Bolt
1005	10011397		Handle-cap shaped
1006	12028711		Handle-door
1007	10011397		Handle-cap shaped
1009	10010274		Screw
1010	10008228		Screw
1011	11032542		Hinge
1012	10011608		Screw
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product




<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
1101	20000151		Door-outer
1102	20000152		Door-inner
1103	10011927		Bolt
1105	10011397		Handle-cap shaped
1106	11033033		Handle-door
1107	10011397		Handle-cap shaped
1108	10010271		Plate
1109	10010274		Screw
1110	10008228		Screw
1111	11032543		Hinge
1112	10011608		Screw
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product



<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0601	11032521		Control module programmed
0601	12025831		Control module not programmed
0602	00418283		Support
0603	12024477	12034882	Control module
0604	12028138		Limiter-temperature
0606	10005470		Control module
0607	00489194		Transformer
0609	10008933		Clip
0610	10010202		Clip
0611	10008207		Ignition cable
0612	12024415		Ignition cable
0613	12028088		Cable harness
0614	12024414		Cable harness
0615	12026845		Cable harness
0616	12028077		Cable harness set
0617	12026925		Cable harness
0620	12026870		Cable harness
0621	12028509		Cable harness
0622	12024436		Cable harness
0623	11032801		Cable harness
0624	12028086		Adapter
0625	12026872		Cable harness
0626	12028087		Cable harness
0627	12028082		Cable harness
0628	12026869		Cable harness
0630	12026867		Cable harness
0635	12028664		Cable harness


0636	12028665		Cable harness
0637	12028666		Cable harness
0638	12028667		Cable harness
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
0605	12028663		Control module
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product
0608	12031987		Connectivity module



<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0801	00497756		Motor
0802	00489178		Bracket
0803	00494383		Pipe connection piece
0804	10007424		Lamp
0805	00709468		Heating element
0806	10010225		Nut
0808	10008183		Socket
0809	00627375		Temperature sensor
0810	00640401		Heating element
0811	20000143		Cover
0812	11032546		Support
0813	10011396		Bolt
0814	12028136		Adapter
0815	00706444		Cover
0816	00479238		Cover
0818	00687604		Plate
0819	00431908		Broil Element
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care



8020	00311902		Ceramic glass care
0807	10010208		Washer
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product




<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0201	12024418		Module-relay
0202	12024417		Module-relay
0203	00617931		Display
0204	11032519		Bracket
0205	00609115		Switch
0206	11032495		Display module not programmed
0207	11032497		Display module not programmed
0207	11032504		Display module programmed
0209	10010232		Encoder
0210	11033021		Light bar
0211	23000468		Support
0213	20000032		Panel-facia
0214	10008212		Screw
0215	10008201		Ring
0216	00418122		Ring
0217	10010231		Encoder
0218	10011598		Knob
0219	10008199		Knob
0221	10011596		Knob
0222	10010228		Ring
0224	12028661		Switch-selector
0225	00617886		Display
0226	10008200		Knob
0227	10010230		Knob
0228	10011924		Knob
0229	10011925		Knob
8010	00466148		Microfiber E-Cloths


8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
0206	12028849		Display module programmed
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product
0212	00623615		Nut
0220	12034239		Display-temperature



0199



<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0101	00146137		Back wall panel
0102	23000092		Back panel
0103	00649417	00752161	Cover
0104	12028699		Back panel
0105	20000392		Panel side
0106	20000393		Panel side
0108	00619081		Connection piece
0109	12028700		Plate
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product
0107	10013545		Latch



<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
1203	00774615		12" Telescopic Rack
1204	00774617		36" Telescopic Rack
1205	11013689		Grill tray
1206	00484628	00449757	Tray for Broiler Pan
1207	00666710		Broiler Pan
1208	00666709		Tray for Broiler Pan
1209	10010207		Bracket
1210	12022200		Sensor
8010	00466148		Microfiber E-Cloths
8011	00311945		Care product
8012	00312007		Care product
8013	00460770		Cleaning Cloth
8014	00311896		Hob detergent
8015	00311897		Hob detergent
8016	00311898		Hob detergent
8017	00311899		Hob detergent
8018	00311900		Ceramic glass care
8019	00311901		Ceramic glass care
8020	00311902		Ceramic glass care
1201	00145306		Grill grid
1202	00637940		Grate Foot Replacement Kit
8021	00311903		Ceramic glass care
8022	15000432		Auxiliary tool
8023	00311908	00312207	Degreaser
8024	00311946		Stainless Steel Cleaning Powder
8025	00311964		Care product