



<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
1301	00145306		Grill grid
1302	00637940		Grate Foot Replacement Kit
1303	00774615		12" Telescopic Rack
1304	00774617		36" Telescopic Rack
1305	11013689		Grill tray
1306	00484628	00449757	Tray for Broiler Pan
1307	00666709		Tray for Broiler Pan
1308	00666710		Broiler Pan
1309	10010207		Bracket
1310	12022200		Sensor




<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0801	00497756		Motor
0802	00489178		Bracket
0803	00494383		Pipe connection piece
0804	10007424		Lamp
0805	00709469		Heating element
0806	10010225		Nut
0807	10010208		Washer
0808	10008183		Socket
0809	00627375		Temperature sensor
0810	00750884		Heater-ring
0811	12028706		Cover
0812	11032546		Support
0813	10011396		Bolt
0814	12028136		Adapter
0815	00706442		Reflector
0816	00479238		Cover
0818	00708175		Plate
0819	11033032		Heating element



0199




<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0101	00146137		Back wall panel
0102	23000092		Back panel
0103	00649417	00752161	Cover
0104	12028699		Back panel
0105	20000392		Panel side
0106	20000393		Panel side
0107	10013545		Latch
0108	00619081		Connection piece
0109	12028700		Plate




<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0901	00497756		Motor
0902	00489178		Bracket
0903	00494383		Pipe connection piece
0904	10007424		Lamp
0905	00709468		Heating element
0906	10010225		Nut
0907	10010208		Washer
0908	10008183		Socket
0909	00627375		Temperature sensor
0910	00640401		Heating element
0911	20000143		Cover
0912	11032546		Support
0913	10011396		Bolt
0914	12028136		Adapter
0915	00706444		Cover
0916	00479238		Cover
0918	00687604		Plate
0919	00431908		Broil Element






<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
1003	10011167		Limiter-temperature
1004	00628372		Terminal
1005	00651285		Latch
1006	00618400		Switch-door
1007	10001186		Plate
1008	12013593		Bolt
1009	10001351		Foot
1010	12032338		Cover
1011	12032339		Cover
1012	12028141		Cover
1014	00649416		Hinge-plate
1015	12028710		Seal-door
1016	20000145		Seal-door
1030	00648862		Cable harness
1001	10020211		Fan motor
1002	10020212		Fan motor





<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0501	11032438		Gas tap
0502	11032439		Gas tap
0503	11032863		Gas tap
0504	11032862		Gas tap
0505	11032440		Gas tap
0506	11032441		Gas tap
0510	00423093		Valve
0512	10003806		Valve
0512	10009155		Valve
0513	20000265		Manifold
0514	00420807		Screw
0514	10003806		Valve
0515	20000140		Manifold
0516	20000265		Manifold
0517	10009569		Bracket
0522	10010270		Pipe connection piece
0523	11033022		Tub complete
0524	00754658		Regulator-pressure
0525	10010200		Adapter
0526	11033031		Hose-inlet
0527	10011592		Extension for inlet



0496





<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0401	10004490		Burner cap
0402	10004489		Burner cap
0403	10004493		Burner
0404	10004492		Burner
0405	10004495		Venturi nozzle
0406	10006471		Electrode
0407	10008211		Screw
0408	10004498		Burner housing
0409	10004497		Burner housing
0410	10004531		Screw
0411	10006793		Jet
0412	10006797		Jet
0413	12007259		Ignition device
0414	00701902		Rail
0415	11013687		Hob top
0416	10008221		Heat shield





<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
1101	20000149		Door-outer
1102	20000150		Door-inner
1103	10011927		Bolt
1105	10011397		Handle-cap shaped
1106	12028711		Handle-door
1107	10011397		Handle-cap shaped
1109	10010274		Screw
1110	10008228		Screw
1111	11032542		Hinge
1112	10011608		Screw







<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0601	12024441		Frame
0602	10008228		Screw
0603	00634163		Clip
0604	00321402		Ring
0605	10008210		Screw
0606	00145749		Grill grid
0607	11030956		Heating element
0608	10008210		Screw
0609	11030067		Grill accessories
0610	11030015		Tray for Ceramic Briquettes (for PABRICKBKW)
0611	00098049		Salver
0612	12004405		Temperature sensor
0613	10008210		Screw
0614	00634165		Bracket
0615	10008210		Screw
0616	12026866		Cable harness



<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
1201	20000151		Door-outer
1202	20000152		Door-inner
1203	10011927		Bolt
1205	10011397		Handle-cap shaped
1206	11033033		Handle-door
1207	10011397		Handle-cap shaped
1208	10010271		Plate
1209	10010274		Screw
1210	10008228		Screw
1210	12022200		Sensor
1211	11032543		Hinge




<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0301	10004490		Burner cap
0302	10004489		Burner cap
0303	10004493		Burner
0304	10004492		Burner
0305	10004495		Venturi nozzle
0306	10006471		Electrode
0307	10008211		Screw
0308	10004498		Burner housing
0309	10004497		Burner housing
0310	10004531		Screw
0311	10006793		Jet
0312	10006797		Jet
0313	12007259		Ignition device
0314	00701902		Rail
0315	00687075		Tray
0316	12024446		Heat shield
0317	10006795		Jet



<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0701	11032521		Control module programmed
0701	12032176	12034869	Control module not programmed
0702	00418283		Support
0703	12024477	12034882	Control module
0704	12028088		Cable harness
0706	10005470		Control module
0707	00489194		Transformer
0708	12028138		Limiter-temperature
0709	10008933		Clip
0710	10010202		Clip
0711	10008207		Ignition cable
0712	12024415		Ignition cable
0713	12028088		Cable harness
0714	12024414		Cable harness
0715	12026845		Cable harness
0716	12028138		Limiter-temperature
0717	12026925		Cable harness
0720	12026870		Cable harness
0721	12028509		Cable harness
0722	12024436		Cable harness
0723	11032801		Cable harness
0724	12028086		Adapter
0725	12026872		Cable harness
0726	12028087		Cable harness
0727	12028082		Cable harness
0728	12026869		Cable harness
0730	12026846		Cable harness





<b>Position ID</b>	<b>Part number.</b>	<b>Replaces:</b>	<b>Description</b>
0201	12024418		Module-relay
0202	12024417		Module-relay
0203	00617931		Display
0204	11032519		Bracket
0205	00609115		Switch
0206	11032495		Display module not programmed
0206	12028852		Display module programmed
0207	11032497		Display module not programmed
0207	11032504		Display module programmed
0209	10010232		Encoder
0210	11033021		Light bar
0211	23000468		Support
0212	00623615		Nut
0213	20000030		Panel-facia
0214	10008212		Screw
0215	10008201		Ring
0216	00418122		Ring
0217	10010231		Encoder
0218	10011598		Knob
0219	10008199		Knob
0221	10011596		Knob
0222	10010228		Ring
0223	10008226		Bracket
0224	00629049		Energy regulator
0225	00617886		Display
0226	10008200		Knob
0227	10010230		Knob

0228	10008225		Knob
0230	12026865		Cable harness
0220	12034239		Display-temperature