



Position ID	Part number.	Replaces:	Description
1201	20000153		Door-outer
1202	20000154		Door-inner
1203	10011927		Bolt
1205	10011397		Handle-cap shaped
1206	11033033		Handle-door
1207	10011397		Handle-cap shaped
1208	10010271		Plate
1209	10010274		Screw
1210	10008228		Screw
1211	11032544		Hinge
1212	00618862		Screw




0396


Position ID	Part number.	Replaces:	Description
0314	00701902		Rail
0301	10004490		Burner cap
0302	10004489		Burner cap
0303	10004493		Burner
0304	10004492		Burner
0305	10004495		Venturi nozzle
0306	10006471		Electrode
0307	10008211		Screw
0308	10004498		Burner housing
0309	10004497		Burner housing
0310	10004531		Screw
0311	10006786		Jet
0312	10006797		Jet
0313	12007259		Ignition device
0315	00687075		Tray
0316	12024446		Heat shield
0317	10006795		Jet




Position ID	Part number.	Replaces:	Description
0701	00778241		Griddle
0702	12024437		Tray
0703	12028074		Heating element
0704	12024439		Retaining plate
0705	12024438		Insulating part
0706	12028085		Cable harness





Position ID	Part number.	Replaces:	Description
0801	11032521		Control module programmed
0801	12025831		Control module not programmed
0802	00418283		Support
0803	12024477	12034882	Control module
0804	12028138		Limiter-temperature
0806	10005470		Control module
0807	00489194		Transformer
0809	10008933		Clip
0810	10010202		Clip
0811	12024415		Ignition cable
0812	12026846		Cable harness
0813	12028088		Cable harness
0814	12024414		Cable harness
0815	12026845		Cable harness
0816	12028077		Cable harness set
0817	12026925		Cable harness
0820	12028090		Cable harness
0823	12026868		Cable harness
0823	12028082		Cable harness
0824	12028086		Adapter
0825	12028066		Cable harness set
0826	12028087		Cable harness
0818	10008207		Ignition cable
0827	12028136		Adapter
0808	12031987		Connectivity module





Position ID	Part number.	Replaces:	Description
0901	00497756		Motor
0902	00489178		Bracket
0903	00494383		Pipe connection piece
0904	10007424		Lamp
0905	00709468		Heating element
0906	10010225		Nut
0908	10008183		Socket
0909	00627375		Temperature sensor
0910	00640401		Heating element
0911	20000143		Cover
0912	20000159		Guide
0913	10011396		Bolt
0915	00706444		Cover
0918	00774121		Deflector
0919	12028075		Heating element
0907	00605039		Washer
0916	00479238		Cover
0920	10010304		Plug
0928	12028136		Adapter




Position ID	Part number.	Replaces:	Description
1001	00497756		Motor
1002	00489178		Bracket
1003	00494383		Pipe connection piece
1004	00627375		Temperature sensor
1004	10007424		Lamp
1005	00709468		Heating element
1006	10010225		Nut
1008	10008183		Socket
1010	00640401		Heating element
1011	20000143		Cover
1012	11032546		Support
1013	10011396		Bolt
1015	00706444		Cover
1018	00687604		Plate
1019	00431908		Broil Element
1007	00605039		Washer
1009	00627375		Temperature sensor
1016	00479238		Cover




Position ID	Part number.	Replaces:	Description
1301	20000151		Door-outer
1302	20000152		Door-inner
1303	10011927		Bolt
1305	10011397		Handle-cap shaped
1306	11033033		Handle-door
1307	10011397		Handle-cap shaped
1308	10010271		Plate
1309	10010274		Screw
1310	10008228		Screw
1311	11032543		Hinge
1312	00618862		Screw



Position ID	Part number.	Replaces:	Description
0601	12024441		Frame
0602	10008228		Screw
0603	00634163		Clip
0604	10010298		Washer
0605	10008224		Screw
0606	00145749		Grill grid
0607	11030956		Heating element
0608	10008210		Screw
0610	11030015		Tray for Ceramic Briquettes (for PABRICKBKW)
0611	00098049		Salver
0612	12004405		Temperature sensor
0613	10008210		Screw
0614	00634165		Bracket
0615	10008210		Screw
0616	12026866		Cable harness
0609	11030067		Grill accessories



Position ID	Part number.	Replaces:	Description
1103	10011167		Limiter-temperature
1104	00628372		Terminal
1105	00651285		Latch
1106	00618400		Switch-door
1107	10001186		Plate
1108	12013593		Bolt
1112	12028141		Cover
1113	12011935		Wheel
1115	20000144		Seal-door
1116	20000145		Seal-door
1130	00648862		Cable harness
1131	00644253		Power cord
1109	10001351		Foot
1114	00655554		Receiver
1111	10014059		Cover
1101	10020211		Fan motor
1102	10020212		Fan motor
1199	12030965		Repair-set




0199


Position ID	Part number.	Replaces:	Description
0101	00146138		Back wall panel
0102	23000092		Back panel
0103	00649417	00752161	Cover
0105	20000137		Panel side
0106	20000138		Panel side
0107	00619081		Connection piece
0109	20000142		Plate
0108	10013545		Latch
0104	10020374		Back panel



0496




Position ID	Part number.	Replaces:	Description
0414	00701902		Rail
0401	10004490		Burner cap
0402	10004489		Burner cap
0403	10004493		Burner
0404	10004492		Burner
0405	10004495		Venturi nozzle
0406	10006471		Electrode
0407	10008211		Screw
0408	10004498		Burner housing
0409	10004497		Burner housing
0410	10004531		Screw
0411	10006793		Jet
0412	10006797		Jet
0413	12007259		Ignition device
0415	11013687		Hob top
0416	10008221		Heat shield




Position ID	Part number.	Replaces:	Description
0201	12024418		Module-relay
0202	12024417		Module-relay
0203	00617931		Display
0204	11032519		Bracket
0205	00609115		Switch
0206	11032495		Display module not programmed
0207	11032497		Display module not programmed
0207	11032508		Display module programmed
0209	10010232		Encoder
0210	00715274		LED-Light bar
0211	20000044	23000469	Support
0213	20000039		Panel-facia
0214	10008212		Screw
0215	10008201		Ring
0216	00418122		Ring
0217	10010231		Encoder
0218	10011598		Knob
0219	10008199		Knob
0221	10011596		Knob
0222	10010228		Ring
0223	10008226		Bracket
0224	00629049		Energy regulator
0225	00617886		Display
0226	10008200		Knob
0227	10010230		Knob
0228	10008225		Knob
0229	10000773		Regulator-temperature

0230	10009568		Knob
0230	12026865		Cable harness
0206	12028862		Display module programmed
0212	00623615		Nut
0220	12034239		Display-temperature



Position ID	Part number.	Replaces:	Description
0515	11032444		Gas tap
0516	20000140		Manifold
0523	11032445		Tube
0501	11032438		Gas tap
0502	11032439		Gas tap
0503	11032444		Gas tap
0504	11032443		Gas tap
0505	11032440		Gas tap
0506	11032441		Gas tap
0510	00423093		Valve
0512	10003806		Valve
0513	10009155		Valve
0514	00420807		Screw
0515	20000141		Manifold
0517	10009569		Bracket
0522	10010270		Pipe connection piece
0524	00754658		Regulator-pressure
0526	11032442		Tube
0527	10011592		Extension for inlet
0528	10011560		Connection piece
0529	10011591		Valve



Position ID	Part number.	Replaces:	Description
1403	00774616		30" Telescopic Rack
1404	00774617		36" Telescopic Rack
1405	11013689		Grill tray
1406	00484628	00449757	Tray for Broiler Pan
1409	10011639		Bracket
1410	12022200		Sensor
1401	00145306		Grill grid
1402	00637940		Grate Foot Replacement Kit