


Position ID	Part number.	Replaces:	Description
0801	00497756		Motor
0804	10007424		Lamp
0805	00709468		Heating element
0806	10010225		Nut
0808	10008183		Socket
0809	00627375		Temperature sensor
0810	00640401		Heating element
0811	20000143		Cover
0812	20000159		Guide
0813	10011396		Bolt
0814	12028136		Adapter
0815	00479238		Cover
0816	00706444		Cover
0818	00774121		Deflector
0819	12028075		Heating element




0396



Position ID	Part number.	Replaces:	Description
0301	10004490		Burner cap
0302	10004489		Burner cap
0303	10004493		Burner
0304	10004492		Burner
0305	10004495		Venturi nozzle
0306	10006471		Electrode
0308	10004498		Burner housing
0309	10004497		Burner housing
0311	10006786		Jet
0312	10006797		Jet
0313	12007259		Ignition device
0314	00701902		Rail
0315	00687075		Tray
0316	12024446		Heat shield
0317	10006795		Jet




0496




Position ID	Part number.	Replaces:	Description
0401	10004490		Burner cap
0402	10004489		Burner cap
0403	10004493		Burner
0404	10004492		Burner
0408	10004498		Burner housing
0409	10004497		Burner housing
0411	10006786		Jet
0412	10006797		Jet
0413	10006793		Jet
0415	10008221		Heat shield
0416	11013687		Hob top




Position ID	Part number.	Replaces:	Description
1101	20000151		Door-outer
1102	20000152		Door-inner
1103	10011927		Bolt
1105	10011397		Handle-cap shaped
1106	11033033		Handle-door
1107	10011397		Handle-cap shaped
1108	10010271		Plate
1110	10008228		Screw
1111	11032544		Hinge
1112	00618862		Screw



Position ID	Part number.	Replaces:	Description
0701	11032521		Control module programmed
0701	12025831		Control module not programmed
0702	00418283		Support
0703	12024477	12034882	Control module
0704	12028138		Limiter-temperature
0706	10005470		Control module
0707	00489194		Transformer
0709	10008933		Clip
0710	10010202		Clip
0712	12024415		Ignition cable
0712	12026846		Cable harness
0713	12028088		Cable harness
0714	12024414		Cable harness
0715	12026845		Cable harness
0716	12028077		Cable harness set
0717	12026925		Cable harness
0720	12028090		Cable harness
0721	10008207		Ignition cable
0723	12026868		Cable harness
0723	12028082		Cable harness
0724	12028086		Adapter
0725	12028066		Cable harness set
0726	12028087		Cable harness
0708	12031987		Connectivity module



Position ID	Part number.	Replaces:	Description
0901	00497756		Motor
0902	00489178		Bracket
0904	10007424		Lamp
0905	00709468		Heating element
0906	10010225		Nut
0907	10010208		Washer
0908	10008183		Socket
0909	00627375		Temperature sensor
0910	00640401		Heating element
0911	11032519		Bracket
0912	20000143		Cover
0913	10011396		Bolt
0914	12028136		Adapter
0915	00706444		Cover
0918	00687604		Plate
0919	00431908		Broil Element



Position ID	Part number.	Replaces:	Description
0201	12024418		Module-relay
0202	12024417		Module-relay
0203	00617931		Display
0204	11032519		Bracket
0205	00609115		Switch
0206	11032495		Display module not programmed
0207	11032497		Display module not programmed
0207	11032508		Display module programmed
0209	10010232		Encoder
0210	00715274		LED-Light bar
0211	23000469		Support
0213	20000038		Panel-facia
0214	10008212		Screw
0215	10008201		Ring
0216	00418122		Ring
0217	10010231		Encoder
0218	10011598		Knob
0219	10008199		Knob
0220	10011638	12034239	Display-temperature
0221	10011596		Knob
0222	10010228		Ring
0224	00623921		Regulator-temperature
0225	00617886		Display
0226	10008200		Knob
0227	10010230		Knob
0228	10009568		Knob
0206	12028863		Display module programmed


0212

00623615


Nut




0199




Position ID	Part number.	Replaces:	Description
0101	00146138		Back wall panel
0102	23000092		Back panel
0103	00649417	00752161	Cover
0105	20000137		Panel side
0106	20000138		Panel side
0107	00619081		Connection piece
0109	20000142		Plate
0108	10013545		Latch
0104	10020374		Back panel




Position ID	Part number.	Replaces:	Description
0601	00145818		Grill plate smooth
0602	11013686		Tray
0603	00445588		Heating element
0604	12028080		Tray
0605	00145856		Retaining plate
0606	00655590		Safety pan retainer
0607	12013517		Spacer
0610	12028084		Cable harness





Position ID	Part number.	Replaces:	Description
1003	10011167		Limiter-temperature
1004	00628372		Terminal
1005	00651285		Latch
1006	00618400		Switch-door
1007	10001186		Plate
1008	12013593		Bolt
1009	10001351		Foot
1009	10010274		Screw
1012	12028141		Cover
1013	12011935		Wheel
1015	20000144		Seal-door
1016	20000145		Seal-door
1030	00644253		Power cord
1030	00648862		Cable harness
1011	10014059		Cover
1001	10020211		Fan motor
1002	10020212		Fan motor
1099	12030965		Repair-set



Position ID	Part number.	Replaces:	Description
1302	00637940		Grate Foot Replacement Kit
1303	00774616		30" Telescopic Rack
1304	00774617		36" Telescopic Rack
1305	11013689		Grill tray
1306	00484628	00449757	Tray for Broiler Pan
1309	10011639		Bracket
1310	12022200		Sensor
1301	00145306		Grill grid



Position ID	Part number.	Replaces:	Description
0501	11032439		Gas tap
0502	11032438		Gas tap
0503	11032444		Gas tap
0504	11032443		Gas tap
0505	11032440		Gas tap
0506	11032441		Gas tap
0510	00423093		Valve
0515	11032444		Gas tap
0516	20000140		Manifold
0517	10009569		Bracket
0522	10010270		Pipe connection piece
0523	11032445		Tube
0524	00754658		Regulator-pressure
0526	11032442		Tube
0527	10011592		Extension for inlet
0528	10011560		Connection piece
0529	10011591		Valve



Position ID	Part number.	Replaces:	Description
1201	20000153		Door-outer
1202	20000154		Door-inner
1203	10011927		Bolt
1205	10011397		Handle-cap shaped
1206	11033033		Handle-door
1207	10011397		Handle-cap shaped
1208	10010271		Plate
1209	10010274		Screw
1210	10008228		Screw
1211	11032543		Hinge
1212	00618862		Screw