



Position ID	Part number.	Replaces:	Description
0901	12028083		Water tank
0902	12004447		Salver
0903	00643179		Sealing
0904	10012026		Nut
0905	10012023		Hose-inlet
0906	00608739		Valve-magnet
0907	00644010		Holder
0908	10012024		Hose-vent
0909	00745311		Trimplate
0910	10012098		Nut
0911	00647003		PC board
0920	00655580		Cable harness
8130	00056317		Hard Water Test Strip




Position ID	Part number.	Replaces:	Description
1101	10011167		Limiter-temperature
1102	00655613		Temperature sensor
1103	12028079		Heating element
1104	11033375		Panel
1105	11033376		Panel
1106	00709841		Slide
1107	00658253		Slide
1108	11035740		Frame
1109	10008224		Screw
1110	12029041		Retaining plate
1111	10004531		Screw
1112	20000136		Drawer
1113	10011397		Handle-cap shaped
1114	12029042		Handle
1115	10011397		Handle-cap shaped
1116	12028891		Insulating part
8130	00056317		Hard Water Test Strip




Position ID	Part number.	Replaces:	Description
0701	11032521		Control module programmed
0701	12032176	12034869	Control module not programmed
0702	00418283		Support
0704	12028138		Limiter-temperature
0706	10005470		Control module
0707	00489194		Transformer
0708	12031987		Connectivity module
0709	10008933		Clip
0710	10010202		Clip
0711	12028887		Steam module not programmed
0711	12028888		Steam module programmed
0712	10008169		Relay
0713	12004817		PC board assembly-mains power
0714	12024414		Cable harness
0715	12026845		Cable harness
0716	12028077		Cable harness set
0717	12026925		Cable harness
0720	12028090		Cable harness
0723	12026868		Cable harness
0724	12028086		Adapter
0725	12028068		Cable harness set
0727	12028082		Cable harness
0728	10008207		Ignition cable
0729	12024415		Ignition cable
0730	12026846		Cable harness
0731	12028089		Cable harness
0740	12028069		Cable harness


0742	12028081		Adapter
0743	12012945		Adapter
8130	00056317		Hard Water Test Strip




Position ID	Part number.	Replaces:	Description
0501	11032438		Gas tap
0502	11032439		Gas tap
0503	11032444		Gas tap
0504	11032443		Gas tap
0505	11032440		Gas tap
0506	11032441		Gas tap
0510	00423093		Valve
0512	10003806		Valve
0513	10009155		Valve
0514	00420807		Screw
0515	20000141		Manifold
0516	20000140		Manifold
0517	10009569		Bracket
0522	10010270		Pipe connection piece
0523	11032445		Tube
0524	00754658		Regulator-pressure
0526	11032442		Tube
0527	10011592		Extension for inlet
0528	10011560		Connection piece
0529	10011591		Valve
8130	00056317		Hard Water Test Strip




Position ID	Part number.	Replaces:	Description
0801	12022204		Fan
0803	00655834		Seal
0804	00623923		Bolt
0805	00655835		Seal
0806	00655759		Lamp
0807	00429173		Limiter-temperature
0808	00623543		Seal
0809	00608933		Temperature sensor
0810	00750884		Heater-ring
0811	00706789		Cover
0812	10012022		Nut
0813	00741834		Grille
0814	00741833		Grille
0815	00614466		Drive
0816	00655612		Spring
0817	00623606		Clip
0818	00659285		Flap
0819	00623544		Seal
0820	00623615		Nut
8130	00056317		Hard Water Test Strip




Position ID	Part number.	Replaces:	Description
1001	00497756		Motor
1002	00489178		Bracket
1003	00494383		Pipe connection piece
1004	10007424		Lamp
1005	00709468		Heating element
1006	10010225		Nut
1007	00605039		Washer
1008	10008183		Socket
1009	00627375		Temperature sensor
1010	00640401		Heating element
1011	20000143		Cover
1012	11032546		Support
1013	10011396		Bolt
1014	12028136		Adapter
1015	00706444		Cover
1016	00479238		Cover
1018	00687604		Plate
1019	00431908		Broil Element
8130	00056317		Hard Water Test Strip



Position ID	Part number.	Replaces:	Description
1501	00145306		Grill grid
1502	00637940		Grate Foot Replacement Kit
1503	00623653		Sponge for Steam Convection Ovens
1504	00774617		36" Telescopic Rack
1505	11013689		Grill tray
1506	00484628	00449757	Tray for Broiler Pan
1507	11006670		Wire Rack for Steam Ovens
1508	11014476		Cooking dish GN
1509	00664949		Unperforated Steam Oven Baking Tray (Large)
1510	00577553		Perforated Steam Oven Pan (Small)
1511	00577552		Unperforated Steam Oven Pan (Small)
1512	12022200		Sensor
1513	10011639		Bracket
8130	00056317		Hard Water Test Strip



Position ID	Part number.	Replaces:	Description
1301	20000148		Door
1302	20000540		Door-inner
1303	10010275		Screw
1305	10011397		Handle-cap shaped
1306	12029042		Handle
1307	10011397		Handle-cap shaped
1308	10011608		Screw
1309	10008228		Screw
1310	10008228		Screw
1311	11032541		Hinge
1312	11033378		Retaining plate
8130	00056317		Hard Water Test Strip




Position ID	Part number.	Replaces:	Description
0201	12024418		Module-relay
0202	12024417		Module-relay
0203	00617931		Display
0204	11032519		Bracket
0205	00609115		Switch
0206	11032495		Display module not programmed
0206	12028865		Display module programmed
0207	11032497		Display module not programmed
0207	11032511		Display module programmed
0209	12028076		Encoder
0210	00715274		LED-Light bar
0211	23000469		Support
0212	00623615		Nut
0213	20000040		Panel-facia
0214	10008212		Screw
0215	10008201		Ring
0216	00418122		Ring
0217	10010231		Encoder
0218	10011598		Knob
0219	10008199		Knob
0221	10011597		Knob
0222	10010228		Ring
0224	00623921		Regulator-temperature
0225	00617886		Display
0226	10008200		Knob
0227	10010230		Knob
0228	10009568		Knob


0229	10010232		Encoder
0230	10011595		Knob-temperature
0220	12034239		Display-temperature
8130	00056317		Hard Water Test Strip




0496





Position ID	Part number.	Replaces:	Description
0401	10004490		Burner cap
0402	10004489		Burner cap
0403	10004493		Burner
0404	10004492		Burner
0405	10004495		Venturi nozzle
0406	10006471		Electrode
0408	10004498		Burner housing
0409	10004497		Burner housing
0411	10006793		Jet
0412	10006795		Jet
0413	12007259		Ignition device
0414	00701902		Rail
0415	11013687		Hob top
0416	10008221		Heat shield
8130	00056317		Hard Water Test Strip






Position ID	Part number.	Replaces:	Description
0301	10004490		Burner cap
0302	10004489		Burner cap
0303	10004493		Burner
0304	10004492		Burner
0305	10004495		Venturi nozzle
0306	10006471		Electrode
0308	10004498		Burner housing
0309	10004497		Burner housing
0311	10006797		Jet
0312	10006795		Jet
0313	12007259		Ignition device
0314	00701902		Rail
0315	00687075		Tray
0316	12024446		Heat shield
0317	10006786		Jet
8130	00056317		Hard Water Test Strip




Position ID	Part number.	Replaces:	Description
1203	10011167		Limiter-temperature
1204	00628372		Terminal
1205	00651285		Latch
1206	00618400		Switch-door
1207	10001186		Plate
1208	12013593		Bolt
1209	10001351		Foot
1213	12011935		Wheel
1216	00645704		Seal-door
1217	11032447		Drawer
1218	20000145		Seal-door
1230	00644253		Power cord
1231	00648862		Cable harness
1211	12032339		Cover
1212	12032338		Cover
1201	10020211		Fan motor
1202	10020212		Fan motor
8130	00056317		Hard Water Test Strip



Position ID	Part number.	Replaces:	Description
1401	20000155		Door-outer
1402	20000156		Door-inner
1403	10011927		Bolt
1405	10011397		Handle-cap shaped
1406	10011397		Handle-cap shaped
1407	10011397		Handle-cap shaped
1408	10010271		Plate
1409	10010274		Screw
1410	10008228		Screw
1411	11032545		Hinge
1412	10011608		Screw
8130	00056317		Hard Water Test Strip



Position ID	Part number.	Replaces:	Description
0601	00145818		Grill plate smooth
0602	11013686		Tray
0603	11028221		Heating element
0604	12024439		Retaining plate
0605	00146178		Retaining plate
0607	12031544		Spacer
0610	12028084		Cable harness
8130	00056317		Hard Water Test Strip



0199

Position ID	Part number.	Replaces:	Description
0101	00146138		Back wall panel
0102	23000092		Back panel
0103	00649417	00752161	Cover
0104	11033374		Panel
0105	20000137		Panel side
0106	20000139		Panel side
0107	00619081		Connection piece
0108	10013545		Latch
0109	20000142		Plate
8130	00056317		Hard Water Test Strip