



Position ID	Part number.	Replaces:	Description
1001	00145748		Grill grid
1002	00145747		Grill grid
1003	00637940		Grate Foot Replacement Kit
1004	00774613		30" Telescopic Rack
1005	11013689		Grill tray
1006	00484628	00449757	Tray for Broiler Pan
1007	10010207		Bracket
1008	00712470		Shelf




Position ID	Part number.	Replaces:	Description
0802	00643600		Cooling Fan
0804	00628372		Terminal
0806	00618400		Switch-door
0807	10001186		Plate
0808	10011170		Bolt
0809	10001351		Foot
0810	00649416		Hinge-plate
0811	12028040		Seal-door
0812	00146142		Cover sheet
0813	00656311	00752651	Power cord
0801	10020211		Fan motor




0199




Position ID	Part number.	Replaces:	Description
0101	00146128		Back wall panel
0102	11031592		Back panel
0103	00649417	00752161	Cover
0104	00719241		Panel side
0105	00719242		Panel side
0106	00770922		Cover
0107	00623741		Screw
0108	00714354		Hob top
0109	10008198		Heat shield




0701



0702




0704




0704

0715


0716



0721




0709



0717


0718




0713



0703




0711




0712

0713



0705


0710



0712

0713

0713




0720

0715





0796


Position ID	Part number.	Replaces:	Description
0701	00497756		Motor
0702	00489178		Bracket
0703	00479238		Cover
0704	10007424		Lamp
0705	20000102		Lining
0709	00627375		Temperature sensor
0710	11030966		Plate
0711	11030909		Cover
0712	00146140		Support
0713	11032400		Tube
0715	00492431		Igniter
0716	00600909		Bracket
0717	11030965		Burner
0718	00445814		Guide
0720	11032345		Burner pipe
0721	10010304		Plug



Position ID	Part number.	Replaces:	Description
0201	12024418		Module-relay
0202	12024417		Module-relay
0203	00617931		Display
0205	00609115		Switch
0206	10010239		Knob
0207	10010238		Encoder
0208	23000458		Support
0209	00623615		Nut
0210	00146143		Panel-facia
0211	10008212		Screw
0212	10008201		Ring
0213	00418122		Ring
0214	10008199		Knob
0215	10010237		Knob
0216	10010236		Knob
0217	10008200		Knob




Position ID	Part number.	Replaces:	Description
0901	20000063		Door-outer
0902	20000065		Door-inner
0903	10010275		Screw
0904	10011398		Bracket
0905	10011397		Handle-cap shaped
0906	11032089		Handle
0907	10011397		Handle-cap shaped
0908	10010271		Plate
0909	10010274		Screw
0910	10008228		Screw
0911	10011376		Hinge
0912	10011608		Screw




Position ID	Part number.	Replaces:	Description
0501	11032262		Gas tap
0502	11032261		Gas tap
0503	11032265		Gas tap
0504	11032264		Gas tap
0505	00423093		Valve
0506	10010197		Bracket
0507	11030912		Gas tap
0508	10010200		Adapter
0509	00754658		Regulator-pressure
0510	10003806		Valve
0511	00420807		Screw
0512	20000071		Manifold
0513	10009569		Bracket
0514	10010270		Pipe connection piece
0515	11032400		Tube
0516	10009155		Valve
0517	00779008		Manifold
0518	00601543		Connection
0519	10010307		Adapter
0519	10011560		Connection piece
0520	00427661		Connection piece
0521	12026926		Tube
0522	11030964		Gas tap
0523	12026924		Tube
0524	00605061		Valve-two way
0525	20000072		Gas tap



0396




Position ID	Part number.	Replaces:	Description
0301	10004491		Burner cap
0302	10004489		Burner cap
0304	10004494		Burner
0305	10004492		Burner
0306	10006471		Electrode
0307	10008211		Screw
0308	10004496		Venturi nozzle
0309	10004495		Venturi nozzle
0310	10004531		Screw
0311	10004499		Burner housing
0312	10004497		Burner housing
0313	10006791		Jet
0314	10006797		Jet
0315	12007259		Ignition device



Position ID	Part number.	Replaces:	Description
0601	11032521		Control module programmed
0601	12032176	12034869	Control module not programmed
0602	00418283		Support
0603	00489194		Transformer
0604	10008933		Clip
0605	10010202		Clip
0610	10008207		Ignition cable
0611	12024415		Ignition cable
0612	12026846		Cable harness
0613	12028038		Control mechanism
0614	12024414		Cable harness
0615	12033559		Cable harness
0616	10010201		Adapter
0620	12026848		Cable harness
0621	12026928		Cable harness
0607	00423966		Cable strap



0496



Position ID	Part number.	Replaces:	Description
0401	10004491		Burner cap
0402	10004490		Burner cap
0404	10004494		Burner
0405	10004493		Burner
0406	10006471		Electrode
0407	10004531		Screw
0408	10004496		Venturi nozzle
0409	10004495		Venturi nozzle
0411	10004499		Burner housing
0412	10004498		Burner housing
0413	10006791		Jet
0414	10008196		Jet
0415	12007259		Ignition device
0416	10006793		Jet