




Position ID	Part number.	Replaces:	Description
1002	00643600		Cooling Fan
1003	10011167		Limiter-temperature
1004	00628372		Terminal
1005	00651285		Latch
1006	00618400		Switch-door
1007	10001186		Plate
1008	12013593		Bolt
1012	12028141		Cover
1017	10012001		Cover
1018	12028598		Cover
1009	10001351		Foot
1014	00655554		Receiver
1015	12028710		Seal-door
1016	20000145		Seal-door
1010	10014059		Cover
1001	10020211		Fan motor
1019	10020212		Fan motor
1099	12030965		Repair-set




Position ID	Part number.	Replaces:	Description
1201	20000151		Door-outer
1202	20000152		Door-inner
1211	11032543		Hinge
1203	10011927		Bolt
1205	10011397		Handle-cap shaped
1206	11033033		Handle-door
1207	10011397		Handle-cap shaped
1208	10010271		Plate
1209	10010274		Screw
1210	10008228		Screw
1212	10011608		Screw



0896



Position ID	Part number.	Replaces:	Description
0801	00497756		Motor
0802	00489178		Bracket
0803	00655581		Plate
0804	10007424		Lamp
0806	10010225		Nut
0808	10008183		Socket
0809	00627375		Temperature sensor
0810	00146150		Heat shield
0811	12028706		Cover
0812	11032546		Support
0813	10011396		Bolt
0816	00600909		Bracket
0820	00701957		Burner
0807	00605039		Washer
0815	00492431		Igniter
0805	11036762		Cover




Position ID	Part number.	Replaces:	Description
0701	11032521		Control module programmed
0701	12025831		Control module not programmed
0702	00418283		Support
0703	12024477	12034882	Control module
0704	12028138		Limiter-temperature
0706	10005470		Control module
0707	00489194		Transformer
0709	10008933		Clip
0710	10010202		Clip
0711	10008207		Ignition cable
0712	12024415		Ignition cable
0713	12028783		Cable harness
0714	12024414		Cable harness
0715	12028039		Cable harness
0716	12028077		Cable harness set
0717	12026925		Cable harness
0720	12026870		Cable harness
0721	12028509		Cable harness
0722	12024436		Cable harness
0723	11032801		Cable harness
0724	12028086		Adapter
0725	12028683		Cable harness
0726	12028784		Adapter
0727	12028597		Cable harness
0728	12028087		Cable harness
0729	12028082		Cable harness
0730	12026846		Cable harness


0731	12028136		Adapter
0732	00656309	00752650	Power cord
0708	12031987		Connectivity module
0733	00423966		Cable strap



0199




Position ID	Part number.	Replaces:	Description
0101	00146137		Back wall panel
0102	23000092		Back panel
0103	00649417	00752161	Cover
0104	12028699		Back panel
0105	20000392		Panel side
0106	20000393		Panel side
0108	00619081		Connection piece
0109	12028700		Plate
0107	10013545		Latch




Position ID	Part number.	Replaces:	Description
0501	11032438		Gas tap
0502	11032439		Gas tap
0503	11032863		Gas tap
0504	11032862		Gas tap
0505	11032440		Gas tap
0506	11032441		Gas tap
0507	11033158		Gas tap
0508	11033159		Gas tap
0509	11033157		Gas tap
0510	11033160		Gas tap
0513	00607662		Connection
0514	00423093		Valve
0516	10011560		Connection piece
0517	00601543		Connection
0518	00425942		Pipe connection piece
0520	10010270		Pipe connection piece
0521	11033161		Gas tap
0522	10003806		Valve
0523	10009155		Valve
0524	00420807		Screw
0526	20000265		Manifold
0527	10009569		Bracket
0527	20000140		Manifold
0528	00754658		Regulator-pressure
0529	10010200		Adapter
0530	11033031		Hose-inlet
0531	10011592		Extension for inlet

0511	00605061		Valve-two way
0512	11034095		Gas tap
0515	11034096		Gas tap
0525	20000140		Manifold



Position ID	Part number.	Replaces:	Description
1301	00145306		Grill grid
1303	00774615		12" Telescopic Rack
1304	00774617		36" Telescopic Rack
1305	11013689		Grill tray
1306	00484628	00449757	Tray for Broiler Pan
1307	00666710		Broiler Pan
1308	00666709		Tray for Broiler Pan
1309	10010207		Bracket
1310	12022200		Sensor
1302	00637940		Grate Foot Replacement Kit




Position ID	Part number.	Replaces:	Description
0201	12024418		Module-relay
0202	12024417		Module-relay
0203	00617931		Display
0204	11032519		Bracket
0205	00609115		Switch
0206	11032495		Display module not programmed
0207	11032497		Display module not programmed
0207	11032514		Display module programmed
0209	10011872		Switch-selector
0210	11033021		Light bar
0211	20000043	23000468	Support
0213	20000030		Panel-facia
0214	10008212		Screw
0215	10008201		Ring
0216	00418122		Ring
0217	10010231		Encoder
0218	10011598		Knob
0219	10008199		Knob
0221	10012000		Ring
0222	10011873		Ring
0224	00629049		Energy regulator
0225	00617886		Display
0226	10008200		Knob
0227	10010230		Knob
0228	10008225		Knob
0223	10011902		Bracket
0206	12028846		Display module programmed



0212	00623615		Nut
0220	12034239		Display-temperature



0996




Position ID	Part number.	Replaces:	Description
0901	00497756		Motor
0902	00489178		Bracket
0903	00479238		Cover
0904	10007424		Lamp
0906	10010225		Nut
0908	10008183		Socket
0909	00627375		Temperature sensor
0910	11030966		Plate
0911	20000143		Cover
0912	11032546		Support
0913	10011396		Bolt
0916	00600909		Bracket
0917	11032929		Burner
0920	11032930		Burner
0918	00445814		Guide
0905	23000287		Cover
0907	00605039		Washer
0915	00492431		Igniter




Position ID	Part number.	Replaces:	Description
0601	12024441		Frame
0602	10008226		Bracket
0603	00634163		Clip
0604	10010298		Washer
0605	10008224		Screw
0606	00145749		Grill grid
0607	11030956		Heating element
0608	10008210		Screw
0609	11030067		Grill accessories
0610	11030015		Tray for Ceramic Briquettes (for PABRICKBKW)
0611	00098049		Salver
0612	12004405		Temperature sensor
0613	10008210		Screw
0614	00634165		Bracket
0615	10008210		Screw
0616	12024442		Cable harness



0496





Position ID	Part number.	Replaces:	Description
0401	10004490		Burner cap
0402	10004489		Burner cap
0403	10004493		Burner
0404	10004492		Burner
0405	10004495		Venturi nozzle
0406	10006471		Electrode
0408	10004498		Burner housing
0409	10004497		Burner housing
0411	10006793		Jet
0412	10006797		Jet
0413	12007259		Ignition device
0415	11013687		Hob top
0416	10008221		Heat shield
0414	00701902		Rail
0407	10008211		Screw
0410	10004531		Screw



0396

Position ID	Part number.	Replaces:	Description
0301	10004490		Burner cap
0302	10004489		Burner cap
0303	10004493		Burner
0304	10004492		Burner
0305	10004495		Venturi nozzle
0306	10006471		Electrode
0308	10004498		Burner housing
0309	10004497		Burner housing
0311	10006793		Jet
0312	10006797		Jet
0313	12007259		Ignition device
0315	00687075		Tray
0316	12024446		Heat shield
0317	10006795		Jet
0314	00701902		Rail
0307	10008211		Screw
0310	10004531		Screw



Position ID	Part number.	Replaces:	Description
1101	20000149		Door-outer
1102	20000150		Door-inner
1111	11032542		Hinge
1103	10011927		Bolt
1105	10011397		Handle-cap shaped
1106	12028711		Handle-door
1107	10011397		Handle-cap shaped
1109	10010274		Screw
1110	10008228		Screw
1112	10011608		Screw