

CT36E PARTS LIST

Ref #	Part #	Description
1	804744	Glass Ceran Assy With Keypad Invensy, 36", Sst (See S/N Breaks)
	804745	Glass Ceran Assy With Keypad Invensys, 36", Blk (See S/N Breaks)
	804746	Glass Ceran Assy With Keypad Invensey, 36", Plt
2	801351	Screw, 6 x3/8"
3	807073	Board, Control, 36"
4	803143	Cable, Ribbon, 36"
5	802613	Light, Indicator
6	801864	Element Assy., Triple, 2700 Watt, 36"
7	801861	Element Assy., Single, 1500 Watt, 30", 36"
8	801863	Element Assy., Double, 2200 Watt, 30", 36"
9	801860	Element Assy., Single, 1200 Watt, 30", 36"
10	801862	Element Assy., Single, 1800 Watt, 36"
11	800430	Box, Burner, Inner, Insulation, 36"
12	806717	Box, Burner, Inner Assy., 36" (See S/N Breaks)
13	807072	Board, Relay, 36"
14	800414	Blower, Transverse
15	806715	Box, Burner, Outer Assy, 36" (See S/N Breaks)
16	802668	Guard, Fan
17	802669	Retainer, Fan, Rivet
18	800511	Element, Spring
19	806655	Moisture Barrier, CT36E
20	806035	Power Board Mtg Bracket 30
21	806023	Cooktop Fan Mounting Bracket
22	800413	Power Conduit

Not Shown

Part #	Description
800413	Power Conduit w/Terminal Block
800419	Terminal Block
801046	Scraper, Cooktop
801048	Gasket, Rubber, Cooktop Surround
801101	Cleaning Cream
800909	Harness, Element, 36"
802709	Hold Down Clamp Kit
802666	Harness, Fan, 36"
800910	Harness, Power, Inlet, 36"
802772	Grommet, Edge

CT36E EXPLODED VIEW

