

LABEL NO.	ITEM NO.	ITEM NO. DESC.
1	730155	TOP COVER
2	730901	RETAINER-MAIN SHAFT
3	738424	RETAINER-TRANSMISSION SHAFT
4	738426	GEAR HOUSE COVER
5	738006	CASE-GEAR HOUSE
6	730219	SUPPORT OF TOP COVER
7	730256	PLATE-GEAR HOUSE
8	738035	CONTROL PANEL
9	738442	PLANETARY SHAFT
10	738443	52T GEAR
11	738013	CHIMNEY WITH SEAL
12	738444	GEAR
13	738445	TRANSMISSION SHAFT
14	738446	14T GEAR
15	738017	SPACER
16	738018	SPACER
17	738447	37T GEAR
18	738419	CLUTCH GEAR
19	738021	SPACER
20	738448	43T GEAR
21	738024	PULLEY
22	738449	SHAFT-PULLEY
23	738440	26T GEAR
24	738436	MOTOR SUPPORT
25	738028	PULLEY
26	738435	MOTOR
27	730902	KEY
28	730903	KEY
29	730881	KEY
30	730880	KEY
31	730831	KEY
32	730904	KEY
33	730210	BEVEL PINION (14T)
34	730211	HUB ATTACHMENT
35	730162	ATTACHMENT HOLE PLUG
36	730078	THUMB SCREW
37	730163	HANDLE
38	730208	HANDLE SEAT
39	730164	HANDLE KNOB
40	730864	BOLT
41	730205	SHIFTER HUB
42	730207	BRACKET
43	738427	SHIFTING SHAFT GEAR
44	738428	SHIFTING FORK
45	738429	FORK SHAFT
46	730086	COMPRESSION SPRING
47	738433	INTERNAL GEAR
48	738434	PINION GEAR
49	730167	OIL SEAL SEAT
50	730168	PLANETARY HEAD
52	730169	AGITATOR SHAFT
53	730170	TAPERED PIN
54	730171	HINGE SHAFT-TOP COVER
55	730290	COLUMN
56	730172	SLIDEWAY

57	730173	BASE
58	730174	REAR COVER-COLUMN
59	730175	BOWL CLAMP-LEFT
60	730176	BOWL CLAMP-RIGHT
61	730177	BOWL SUPPORT
62	730178	BOWL RETAINER
63	730179	BOWL LOCATING PIN
64	730180	APRON
65	730181	WHEEL HANDLE
66	730182	LIFTING WHEEL
67	730183	CLAMPING ARM
68	730184	WHEEL SHAFT
69	730185	WHEEL BRACKET
70	730186	LIFTING GEAR (41 T)
71	730254	LIFTING SCREW
72	730187	LIFTING NUT
73	730188	RETAINER
74	730189	GEAR (31T)
75	730190	BEVEL GEAR (23T)-LIFTING
76	730191	SHAFT
77	730192	BEVEL GEAR (23T)-WHEEL
78	730193	AL FLAT BEATER
79	730194	AL WIRE WHIP
80	730195	AL DOUGH HOOK
81	730196	BOWL
82	730197	BOWL TRUCK
83	738492	HEAD RING-SAFETY GUARD
84	738493	MOVING COVER-WIRE
85	730893	BOLT
86	730212	SHAFT SEAT-MIRCO SWITCH
87	730311	BALL BEARING
88	738178	BALL BEARING
90	730309	BALL BEARING
91	730309	BALL BEARING
92	730314	BALL BEARING
93	730311	BALL BEARING
94	730291	BALL BEARING
95	730870	BALL BEARING
96	730292	BEARING
97	730408	LOCK NUT
98	738161	LOCK WASHER
99	738432	SPRING OF SHIFT FORK
100	738431	PLUG OF SHIFT FORK
101	730410	LOCK NUT
102	730406	LOCK WASHER
103	730905	SPRING PIN
104	738430	SHIFTING CAM
105	730874	OIL SEAL
106	730875	OIL SEAL
107	730876	OIL SEAL
108	738120	SPACER
109	738121	SPACER
110	730879	KEY
111	730327	O-RING
112	738422	FIXED RING
113	730324	O-RING

114	730765	WASHER
117	738045	SET SCREW
119	738469	OIL PUMP
120	730831	KEY
121	730880	KEY
122	730881	KEY
126	730035	SCREW PLUG
137	730201	COMPRESSION SPRING
138	730213	CONTROL SHAFT-MICRO SWITCH
139	730214	SCREW-SHAFT SET
140	730884	SPRING PIN
141	730885	SPRING PIN
142	730745	SPRING PIN
143	730886	SPRING PIN
144	730906	BOLT
145	730888	BOLT
146	730809	BOLT
147	730838	BOLT
148	730907	BOLT
149	730888	BOLT
151	730908	CAP SCREW
152	730801	TAPERED PIN
153	730867	BOLT
154	730892	BOLT
155	730812	BOLT
156	738422	FIXED RING
157	730894	CAP SCREW
158	730895	CAP SCREW
160	730896	CAP SCREW
161	730897	CAP SCREW
162	730846	CAP SCREW
163	730898	CAP SCREW
164	730841	CAP SCREW
165	730899	CAP SCREW
167	730813	MAC. SCREW
168	730788	MAC. SCREW
169	730791	MAC. SCREW
170	73774	FLAT WASHER
172	730521	SPRING WASHER
173	730526	SPRING WASHER
174	730524	SPRING WASHER
175	730849	NUT
176	730763	NUT
177	730900	NUT
178	738503	STEEL BALL
179	730909	NUT
181	730428	O RING
182	730910	MAC. SCREW
183	730849	NUT
210	736CPB	FRONT PANEL
211	738465	SEAT OF CONTACTOR
212	738417	OIL TUBE
213	730911	BELT
214	738162	LOCK NUT
215	738163	LOCK WASHER



AX-M60P