

LABEL NO.	ITEM NO.	ITEM NO. DESC.
1	738002	PLANETARY BEARING RETAINER
2	738425	BEARING RETAINER A
3	738004	BEARING RETAINER B
4	738005	GEAR HOUSING COVER
5	738006	TRANSMISSION CASE
6		OIL PUMP (GEAR BOX)
7	738009	SUPPORT OF TOP COVER
8		
9	738001R	TOP COVER
10	738011	PLANETARY SHAFT
11	738012	GEAR 50T
12	738013	CHIMNEY
13	730209	BEVEL GEAR
14	738015	TRANSMISSION SHAFT
15	738016	SPIRAL GEAR 16T
16	738017	SPACER
17	738018	COPPER WASHER
18	738019	GEAR 19T
19	738020	CLUTCH GEAR
20	738021	COPPER WASHER
21	738023	GEAR 32T
22		
23	738024	PULLEY (MOTOR)
24	738025	TRANSMISSION SHAFT
25	738026	GEAR 26T
26	738027	MOTOR FIX PLATE
27	738028	PULLEY (TRANSMISSION CASE)
28	738029	MOTOR(220V/60HZ/3PH)4/8P
29	730210	BEVEL GEAR
30	730211	HUB ATTACHMENT
31	730162	PLUG
32	730078	THUMB SCREW
33		
34	738035	CONTROL PANEL
35	738036	HANDLE
36	738037	SHIFTIN SHAFT
37	738038	SHIFT FORK
38	738450	SHIFTER SHAFT
39		
40	730208	HANDLE SEAT
41	738042	SHIFTING CAM
42	738043	PLUG
43	738044	COMPRESSING SPRING
44	738045	SET SCREW
45	730164	HANDLE KNOB
46	738047	SHIFTER HUB
47	738048	BRACKET
48	738049	COMPRESSING SPRING
49	730165	INTERNAL GEAR
51	730166	GEAR 18T
52	730167	SEAT OF OIL SEAL
53	738054	PLANETARY HEAD
54		OIL PUMP (PLANETARY HEAD)
55	738437	PLANETARY SHAFT
56	730170	TAPER PIN
57	730171	FIX BAR OF TOP COVER

58	738059	COLUMN
59	730172	SLIDE WAY
60	738061	BASE
61	730174	REAR COVER(COLUMN)
62	730175	BOWL CLAMP(LEFT)
63	730176	BOWL CLAMP(RIGHT)
64		
65	738066	BOWL SUPPORT
66	738067	BOWL RETAINER
67	738068	BOWL LOCATING PIN
68	730180	APRON
69	738070	REDUCER MOTOR(BOWL LIFT)
70	738074	CHAIN GEAR
71		
72		
73		
74	738075	LIFTING SCREW GEAR
75	730187	LIFTING NUT
76	730188	FIX PLATE
77	730914	80QT BOWL
81	738082	BEATER
82	738083	BOWL TRUCK
83	738085	WIRE WHIP
85	738086	DOUGH ARM
86	738087	HEAD RING
87	738088	WIRE GUARD
88	730200	FIX RING
89	738441	REAR COVER
90		
91	730214	CONTROL SHAFT SCREW
92	738423	CONTROL SHAFT
93	730201	COMPRESSING SPRING
94	730212	CONTROL SHAFT SEAT
113	730849	NUT
114	730915	NUT
115	730763	NUT
116	730900	NUT
117	730765	FLAT WASHER
118	73774	WASHER
119	738120	SPACER
120	738121	SPACER
121	730874	OIL SEAL
122	730875	OIL SEAL
123	730605	OIL SEAL
124	730873	OIL SEAL
125	730916	SET SCREW
126	730786	SET SCREW
127	730917	C TYPE SNAP RING
128	730918	MACH. SCREW
129	730919	CAP SCREW
130	730521	SPRING WASHER
131	738132	SPRING WASHER
132	730526	SPRING WASHER
133	730904	KEY
134	730911	BELT
135	730292	BEARING
136	730476	BALL

137	730801	TAPER PIN
138	738139	OIL CUP
139	730534	FLAT WASHER
140	738141	WHEEL
141	730920	BOLT
142	730907	BOLT
143	730867	BOLT
144	730921	BOLT
145	730893	BOLT
146	730922	BOLT
147	730888	BOLT
148	730923	BOLT
149	730908	BOLT
150	730895	SET SCREW
151	730846	SET SCREW
152	730894	SET SCREW
153	730924	SET SCREW
154	730896	SET SCREW
155	730845	SET SCREW
156	730814	SET SCREW
157	730898	SET SCREW
158	730815	SET SCREW
159	730408	LOCK WASHER
160	738161	LOCK NUT
161	738162	LOCK WASHER
162	738163	LOCK NUT
163	730406	LOCK WASHER
164	730410	LUCK NUT
165	730885	SPRING PIN
166	730925	SPRING PIN
167	730926	SPRING PIN
168	730886	SPRING PIN
169	730905	SPRING PIN
170	730314	BALL BEARING
171	730311	BALL BEARING
172	730291	BALL BEARING
173	730870	BALL BEARING
174	730927	BALL BEARING
175	738176	BALL BEARING
176	738177	BALL BEARING
177	738178	BALL BEARING
178	730881	KEY
179	730902	KEY
180	730903	KEY
181		KEY
182	730880	KEY
183	730929	KEY
184	730879	KEY
185	730831	KEY
186	730930	KEY
187	730813	MACH. SCREW
188	730791	MACH. SCREW
189	730904	KEY
191	730930	KEY
192	738193	CHAIN



AX-M80