

Location of Rating Plate







Sealed Burner

*The rating plate is **under the griddle or storage drawer area.**

Open Burner

*The rating plate is located **under the cooktop** which can be accessed by removing grates and lifting top portion of cooktop or **under Right Front burner.**