




Exploded View & Parts: Models 4120/4130; 5120/5130

Section 7-3



Exploded View & Parts:

Models 4120/4130; 5120/5130

Section 7-3

WHEN ORDERING PORCELAIN PANELS, PLEASE SPECIFY COLOR

1110	Oven Door Handle Stanchion	6437	Oven Door Hinges L & R (not shown)
1115	Hardwood Door Handle	6455	Broiler Pan & Cover
1120	Outer Oven Door Panel	6522	Exhaust Deflector
1125	Oven Door Thermometer (Non Functional)	6536	Cabinet Wrap Weldment
1302	Fire Door Panel	6677	Exhaust Adapter Boot to 6" Diameter
1307	Fire Door Frame	6675	Exhaust Filter (30")
1311	Ash Pan Door - Complete	6676	Exhaust Filter (48")
H-306	Ash Door Hinge Pin (not shown)	6679	Exhaust Blower
1320	Wire Spring Handle	6914	Drawer Assembly
1325	Bell Damper Handle	7159	Burner Control Knob
1330	Bell Damper	7199	Spark Module 0+2 (48" only)
1521	Splash Back	7235	Grate - Cast
1545	Cresting Panel	7322	Hex nut M22 x 1
1546	Heartland nameplate/Clips	7329	Medium Burner Cap
1551	Right Cabinet Bracket	7330	Large Burner Cap
1556	Left Cabinet Bracket	7332	Burner tube
1570	Lower Cabinet Strip	7344	Ignition Switch Top Burner
1575	Upper Cabinet Strip	7366	Control Valve Medium Burner
1588	Right Cabinet Corner	7367	Control Valve Large Burner
1592	Left Cabinet Corner	7369	Medium Jet Holder
1596	Right Cresting Corner	7375	Large Jet Holder
1599	Left Cresting Corner	7425	Medium Burner Base
1607	Front Cabinet Door Panel	7426	Large Burner Base
1610	Cabinet Door Handle	7405	24" Igniter Wire
1660	Reservoir Insert Panel	7406	36" Igniter Wire
2455	Base Rail - Front (48")	7407	48" Igniter Wire
2456	Base Rail - Rear (48")	7402	Spark Module 0+5 (48" & 30")
4012	Base Leg	7430	Spark Igniter
4523	Splash back	7431	Spark Ignitor spring clip
4545	Cresting Panel	8200	Light Socket & Housing
4570	Lower Cabinet Strip	8202	Oven Light Assembly w/light bulb
4575	Upper Cabinet Strip	8204	Oven Lens
4607	Cabinet Door	8313	Front Band
5203	Reservoir Front	8455	Base Rail - Front and side
5310	Stove Top - 48"	8456	Base Rail - Rear (30")
5311	Control Cover Plate -48" (not shown)	8536	Cabinet Wrap
5312	Stove Top - 48"	9105	Drawer - Front Panel
5313	Control Cover Plate - 30" (not shown)	9106	Utility Drawer Frame
5955	48" Combo Manifold Weldment	9141	Oven Door Frame Weldment
5956	30" Combo Manifold Weldment	9142	Oven Door Gasket
6029	Ash Catch	9143	Lower Oven Door Gasket
6163	Bake/Broil Knob	9234	Self Clean Electronic Timer
6171	Indicator Light	9235	Electronic Timer
6176	Ash Door Hinge (not shown)	9239	Broiler Element
6177	Ash Door Catch	9241	Bake Element
6197	2 Speed Blower Control Switch	9449	Oven Rack Support (4 position)
6198	Range Light Switch	9452	Oven Rack
6202	Oven Light Bulb - 40 W	H-4281	Burner Washer
6313	Front Band	H-692	Easy Glide Castor 1" Diameter (not shown)
6347	Oven/Broiler Control		
6348	Self Clean Oven/Broiler Control		
6384	Self Clean Rocker Switch		
6387	Self Clean Oven Door Gasket		