







9000-##-# 30" GAS STOVE

(Parts illustrated for both cone and sealed burner variations)



PAGE ID	MODEL 9000 (DISCONTINUED)	
PART# / ITEM #	DESCRIPTION	NOTES
1115	Oven Door Handle (Wood)	
1125	Oven Door Thermometer (Non-Functional)	
1170	Cabinet Spring Catch	
1546	Heartland Nameplatew/ Clips	Subs to Part# 3599
1550	Right Cabinet Bracket	This Part No Longer Available, May Be Replaced With 1551, 1556 And 45211-# Splashback. Some Drilling For Mounting Holes May Be Required.
1555	Left Cabinet Bracket	This Part No Longer Available, May Be Replaced With 1551, 1556 And 45211-# Splashback. Some Drilling For Mounting Holes May Be Required.
1588	Right Cabinet Cast Corner	Subs To 8015-# Assembly - Refer To Colour Legend For Colour Options
1592	Left Cabinet Cast Corner	Subs To 8015-# Assembly - Refer To Colour Legend For Colour Options
1595	Right Cast Cresting Corner	
1600	Left Cast Cresting Corner	
1610	Cabinet Door Handle	Subs to Part# R1609
1621	Left Cabinet Hinge	Subs To 8015-# Assembly - Refer To Colour Legend For Colour Options
1626	Right Cabinet Hinge	Subs To 8015-# Assembly - Refer To Colour Legend For Colour Options
2460	Right And Left Of Base	
4011	Base Legs	Subs to Part# 4012
4570	Lower Cabinet Strip	
4575	Upper Cabinet Strip	
6197	2 Speed Blower Control Switch	
6198	Oven And Cabinet Light Switch	
6202	Oven Light Bulb - 40w	
6212	Snap In Push Switch	
6223	Closet Bracket Gasket-Left	
6226	Closet Bracket Gasket-Right	
6352	Oven Door Hinge Gasket	
6372	Strain Relief .472 Dia	
6373	Closet Power Cord (Gas)	
6452	Oven Rack	for oven w/o side racks #8449
6455	Broiler Pan & Cover 2 Pc	Replaces 6453/6454
6522	Exhaust Deflector	
6641	Gas Control Panel	Subs to Part# 6640
6675	Exhaust Filter	
6677	Exhaust Adapter Boot To 3 1/4 X 10	
6679	Exhaust Blower	
7073	Broiler Drawer Rack	
7114	Roller - Steel -	
7123	Spring - Broiler Drawer	
7138	Oven Burner Gas Line 3/8	
7141	16.5" .25 Aluminum Tube	Subs to Part# 7148
7144	36.00" 3/16 Aluminum Tube Timer To Pilot	
7145	18.00" 3/16 Aluminum Tube Control To Timer	
7150	Cast Street Elbow- 1/2" 90°	
7153	Valve Mounting Screw 1/4-20 X 5/16	Sealed Burner
7154	Valve Screw 10-24 X 1" & Gasket	
7156	Gasket-Small Burner Base	Sealed Burner
7157	Gasket-Medium Burner Base	Sealed Burner
7158	Gasket- Large Burner Base	Sealed Burner
7182	Spark Module-2+1	
7183	Top Burner Control Knob	
7184	Oven Burner Control Knob	

PAGE ID		MODEL 9000 (DISCONTINUED)	
PART# / ITEM #	DESCRIPTION	NOTES	
4380 7185	Gas Regulator (H-W #4670)	Subs to Part# 3556	
7186	Top Burner - Rear (H-W)		
7187	Top Burner - Front (H-W)		
7188	Ignition Switch Top Burner (H-W #S-18)		
7189	Control Valve - Top Burner (H-W #S1854)		
7192	Oven Burner (H-W #2802)		
7193	Ignition Switch - Oven (H-W)		
7194	Thermostat Oven Burner (H-W #5397)		
7195	Igniter With Wire - Oven (H-W)		
7196	Igniter With Wire - Top L.H. (H-W)		
7201	Safety Shut-Off (H-W #5817)		
7203	Oven Pilot	Subs to Part# R7203	
7207	Oven Bottom Pan Assembly		
7212	Gas Solenoid Valve		
7254	Burner Bowl		
7255	Grate - Cast		
7258	1.25 I.D. Burner Washer	Sealed Burner	
7259	1.06 I.D. Burner Washer	Sealed Burner	
7275	Cabinet Bolting Plate	Na	
7351	Compression Sleeve 1/4"	Harper Wyman / Isphording	
7352	Compression Nut 1/4"	Harper Wyman / Isphording	
7400	Spark Module (2+0)	Sealed Burner Style	
7406	36" High Voltage Wire	Sealed Burner	
7408	Electrode - Sealed Burners	Sealed Burner	
7410	Small Burner	Sealed Burner	
7411	Medium Burner	Sealed Burner	
7412	Large Burner	Sealed Burner	
7413	3/4" Burner Mixer Tube	Sealed Burner	
7414	1" Burner Mixer Tube (Lg)	Sealed Burner	
7415	Small Burner Cap	Sealed Burner	
7416	Medium Burner Cap	Sealed Burner	
7417	Large Burner Cap	Sealed Burner	
7420	Small Orifice (Red)	Sealed Burner	
7421	Medium Orifice (Black)	Sealed Burner	
7422	Large Orifice (Clear)	Sealed Burner	
8200	Light Socket & Housing	Part of 8202 Assembly	
8202	Oven Light Assembly W/Light Bulb	Assembly	
8204	Oven Lens	Part of 8202 Assembly	
8307	Curved Band - Cooking Surface	N/A	
8455	Front Of Base		
8456	Rear Of Base	Subs to Part# 8455	
8536	Cabinet Wrap Weldment		
9090	Deflector - Oven Flue		
9106	Utility Drawer Frame		
9129	Oven Door Gasket With Clips	Subs to Part# 9144	
9139	Oven Door Frame Weldment		
9156	Large Oven Door Hinge		
9216	Manifold		
9236	Electronic Timer	Subs to Part# 9235	
9237	Electronic Minute Minder		
9308	30" Gas Top	Sealed Burner Style	
9309	30" Burner Valve Cover-Gas	Sealed Burner Style	
8449	Oven Rack Support(3 Position)		
8452	Oven Rack		
61981	Switch Hole Plug		
H-222	3/4" Locknut - Mixer Tube	Cone Burner Style	
H-223	1" Locknut- Mixer Tube	Cone Burner Style	

PAGE ID		MODEL 9000 (DISCONTINUED)	
PART# / ITEM #	DESCRIPTION	NOTES	
H-418	Fitting 3/16 Tube Breakaway Nut (For 7194)		
H-432	Fitting-3/8 Tube Breakaway-Nut (For 7194)		
H-666	Easy Glide Castor 1" Diameter Assembly	Subs to Part# H-695	
H-224	Brass Gas Manifold Plug		
1120-#	Outer Oven Door Panel	Subs To11201-# - Refer To Colour Legend For Colour Options	
4523-#	Splashback	No Longer Available, May Be Replaced With 1551, 1556 And 45231 # Splashback. Some Drilling For Mounting Holes May Be Required.	
4545-#	Cresting Panel	Subs To 45451-# - Refer To Colour Legend For Colour Options	
4605-#	Front Cabinet Door Panel	Subs To 8015-# Assembly- Refer To Colour Legend For Colour Options	
9105-#	Drawer - Front Panel	Subs To 91051-# - Refer To Colour Legend For Colour Options	
9915-#	Complete Oven Door	Refer To Colour Legend For Colour Options	
7917-#	Broiler Drawer Assembly	Refer To Colour Legend For Colour Options	
Code	COLOUR LEGEND		
-1	ALMOND		
-2	WHITE		
-3	RED		
-4	GREEN		
-5	BLUE		
-6	BLACK		
-7	JADE - DISCONTINUED		
-9	YELLOW - DISCONTINUED		
-S	STAINLESS STEEL		

rev 061009