


# MODEL 6000 ELECTRIC RANGE PARTS CHART



## 6000 ELECTRIC RANGE PARTS LIST

- 0175 Stove Element Polish
- 1115 Oven Door Handle (Wood)
- 1120 Oven Door Panel — Outer
- 1125 Oven Door Thermometer (Non-Functional)
- 1156 Oven Door Spring — Right & Left
- 1170 Cabinet Spring Catch
- 1301 Fire Door Panel
- 1305 Fire Door Frame
- 1311 Ash Pan Door — Complete
- 1316 Ash Door Hinge — Pins
- 1320 Wire Spring Handle
- 1325 Cast Bell Damper Handle
- 1330 Bell Dampers
- 1520 Splash Back
- 1545 Cresting Panel
- 1550 Right Cabinet Bracket
- 1555 Left Cabinet Bracket
- 1585 Right Cabinet Cast Corner
- 1590 Left Cabinet Cast Corner
- 1595 Right Cast Cresting Corner

- 1600 Left Cast Cresting Corner
- 1605 Front Cabinet Door Panel
- 1611 Cabinet Door Handle
- 1620 Left Cabinet Hinge
- 1625 Right Cabinet Hinge
- 1660 Reservoir Front Insert Panel
- 1735 Logo With Clips
- 1660 Reservoir Front Insert Panel
- 2455 Front of Base
- 2456 Rear of Base
- 2460 Right and Left of Base
- 4010 Base Legs
- 6029 Ash Catch
- 6048 Oven Drip Tray
- 6107 Utility Drawer Frame
- 6109 Utility Drawer — Outer Panel
- 6114 Roller For Oven Drawer
- 6152 Switch Knob for Surface Element
- 6153 Switch Knob for Oven Control
- 6154 Switch Seal — Foam
- 6155 Switch Washer — Nylon
- 6176 Hinge — Fire & Ash Door
- 6177 Striker — Fire & Ash Door
- 6184 Stove Top
- 6186 Solid Element — Small 1500W
- 6187 Solid Element — Medium 2000W
- 6188 Solid Element — Large 2400W
- 6189 Element Switch (For Small Element)
- 6190 Element Switch (For Medium Element)
- 6191 Element Switch (For Large Element)
- 6192 Oven Element
- 6193 Broiler Element
- 6194 Oven Control (18" Cap)
- 6195 Broiler Control (60" Cap)
- 6197 Red Indicator Lights
- 6198 Oven and Cabinet Light Switch
- 6199 Oven Light Socket with Leads
- 6200 Closet Light Socket with Tabs
- 6202 Oven Light Bulb — 40W
- 6203 Oven Lens Frame
- 6204 Oven Lens
- 6214 Circuit Breaker — 15A
- 6215 Circuit Breaker — 20A
- 6216 Thermo Disc — Oven Safety
- 6220 Black Enamel Oven Front
- 6227 Oven Door Gasket with Clips
- 6285 Curved Band — Cooking Surface
- 6295 Curved Band — Reservoir
- 6300 Frame Assembly — Oven Door
- 6447 Broiler Pan
- 6449 Broiler Base Rack
- 6451 Broiler Pan Rack
- 6452 Oven Rack
- 6656 Reservoir Front
- 6672 Reservoir Top Plate
- 6673 Reservoir Lid
- 6678 Blower Wrapper
- 6680 Exhaust Blower
- 6681 Exhaust Adapter Boot to 4" Round
- 6682 Mesh Filter
- 6683 Charcoal Filter
- 6689 Blower Receptacle — 3 Wire
- 6690 Blower Speed Control with Knob

**NOTE: WHEN ORDERING PORCELAIN  
PANELS, PLEASE SPECIFY COLOR.**