


KitchenAid®

36" GAS BUILT-IN DOWNDRAFT COOKTOP

MODELS:

KCGD506GSS00 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	
1		Literature Parts	8	W10907868	Orifice (Left Front)	15		Bezel	
	W10848423	Guide, Use & Care		W10849719	Orifice (Left Rear)		W10884725	Stainless	
	W10848427	Instructions, Installation		W10907866	Orifice (Center Front)	16	7201P077-60	Gasket, Infinite Switch	
	W10917793	Diagram, Wiring		W10907867	Orifice (Center Rear)	17	W10814795	Bracket, Switch Mount	
	W10240007	Instructions, LP Conversion		W10907865	Orifice (Right Rear)	18	7101P309-60	Screw	
	9762761	Tips, Safe Cooking (English)		9	Knob, Control	19	W10827923	Clip, Spring (Electrode)	
	W10065852	Tips, Safe Cooking (French)		W10884723	Stainless Kit, Grate	20	W10876259	Electrode (Left Front)	
2		Top, Main	10	W10821816	Black		W10905489	Electrode (Left Rear)	
	W10842064	Stainless		W10826754	Holder, Orifice (10K) (Left Front)		W10876260	Electrode (Center Front)	
3	7101P427-60	Screw	11	W10826751	Holder, Orifice (5k) (Left Rear)		W10876261	Electrode (Center Rear)	
4	W10910375	Kit, Burner Cap		W10826753	Holder, Orifice (15K) (Center Front)		W10876262	Electrode (Right Rear)	
5	W10732969	Spreader, Flame (Left Front)		W10826752	Holder, Orifice (17K) (Right Rear)			FOLLOWING PARTS NOT ILLUSTRATED	
	W10732968	Spreader, Flame (Left Rear)		W10827697	Holder, Orifice (12.5K) (Center Rear)		W10834701	Harness, Main	
	W10732971	Spreader, Flame (Center Front & Right Rear)		W10826752	Holder, Orifice (17K) (Right Rear)		W10835283	Harness, Blower	
	W10732970	Spreader, Flame (Center Rear)		12	W10866564	Switch, Blower		W10858227	Harness, Jumper
6	7101P426-60	Screw		13	4455917	Bracket, Cooktop Mounting		W10831977	Cord, Power
7	3400093	Screw		14	7101P427-60	Screw		W10132200	Relief, Strain
								W10183556	Clip, Wire
								W10909126	Kit, Plenum Screw
								W11022463	Kit, LP Orifice


BLOWER UNIT PARTS



BLOWER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10836514	Assembly, Top Plenum	4	W10837737	Panel, Lower Plenum Access	6	7103P162-60	Nut, Lock
2	W10877782	Assembly, Downdraft Blower	5	W10815866	Filter, Grease	7	7109P086-60	Washer
3	W10837738	Assembly, Lower Plenum						

BURNER BOX PARTS



BURNER BOX PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10235990	Tray, Spill	10	W10844472	Valve	15	W10295997	Screw, Valve
2		Box, Burner (Not Serviced)			(Left Front & Center Rear)	16	W10827689	Assembly, Tube (Left Front)
3	W10258697	Cover, Blower Motor Harness		W10844473	Valve (Left Rear)	17	W10827690	Assembly, Tube (Left Rear)
4	7101P426-60	Screw		W10844471	Valve (Center Front & Right Rear)	18	W10827691	Assembly, Tube (Center Front)
5	W10811211	Bracket, Hat				19	W10827692	Assembly, Tube (Center Rear)
6	W10894861	Cover, Spark	11	W10295996	Bracket, Saddle Valve	20	W10827693	Assembly, Tube (Right Rear)
7	W10475150	Module, Spark	12	W10449143	Regulator, Pressure			
8	W10361756	Fitting, Gas Supply	13	W10140571	Seal, Switch Shaft			
9	W10818266	Assembly, Manifold	14	W10861397	Harness, Switch			

OPTIONAL PARTS NOT INCLUDED

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	W10355010	Cleaner, Kitchen & Appliance