


KitchenAid®

GAS COOKTOP

MODELS:

KCGD506GSS05 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	
1		Literature Parts	8	W10907868	Orifice (Left Front)	13	7101P309-60	Screw	
	W11468900	Owner's Manual		W10849719	Orifice (5K) (Left Rear)	14	W10827923	Electrode, Spring	
	W11466944	Quick Start Guide		W10907866	Orifice (Center Front)	15		Bezel	
	W11565420	Wiring Diagram		W10907867	Orifice (Center Rear)		W10884725	Stainless	
2		Top, Main		W10907865	Orifice (Right Rear)	16	W11508237	Seal, Downdraft Pad	
	W10842064	Stainless		9	Knob, Control	17		Knob, Fan	
3	W10876259	Electrode (Left Front)	10	W11514464	Stainless		W10884723	Stainless	
	W10905489	Electrode (Left Rear)			Grates, Cooktop (Includes 4 Grates)			FOLLOWING PARTS NOT ILLUSTRATED	
	W10876260	Electrode (Center Front)		W11241663	Black		W11465122	Harness, Main	
	W10876261	Electrode (Center Rear)	11	W10826754	Holder, Orifice (10K) (Left Front)		W11190478	Harness, Blower	
	W10876262	Electrode (Right Rear)			Holder, Orifice (5k) (Left Rear)		W11465762	Harness, Jumper	
4	W10910375	Kit, Burner Cap		W10826753	Holder, Orifice (15K) (Center Front)		7101P460-60	Screw, Grounding	
5	W10732969	Flame Spreader (Left Front)		W10826754	Holder, Orifice (12.5K) (Center Rear)		W10831977	Cord, Power	
	W10732968	Flame Spreader (Left Rear)		W10826752	Holder, Orifice (17K) (Right Rear)		W10132200	Relief, Strain	
	W10732971	Flame Spreader (Center Front & Right Rear)		12	W10866564	Switch, Blower		W10183556	Clip, Wire
	W10732970	Spreader, Flame (Center Rear)						W10909126	Kit, Plenum Screw
6	W10673618	Screw						W11022463	Kit, LP Orifice
7	W10814795	Bracket, Switch Mount							


BLOWER UNIT PARTS



BLOWER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10836514	Assembly, Top Plenum	3	W10837738	Assembly, Lower Plenum	5	7109P086-60	Washer
2	W10877782	Assembly, Downdraft Blower	4	W10837737	Panel, Lower Plenum Access	6	7103P162-60	Nut, Lock

BURNER BOX PARTS



BURNER BOX PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10235990	Tray, Spill	10	W11511837	Valve (Left Front & Center Rear)	17	W10827690	Assembly, Tube (Left Rear)
2		Box, Burner (Not Serviced)				18	W10827691	Assembly, Tube (Center Front)
3	W10258697	Cover, Blower Motor Harness		W11511838	Valve (Left Rear)	19	W10827692	Assembly, Tube (Center Rear)
4	7101P426-60	Screw		W11511836	Valve (Center Front & Right Rear)	20	W10827693	Assembly, Tube (Right Rear)
5	W10811211	Bracket, Hat	11	W10949105	Bracket, Saddle Valve	21	W11508234	Seal, Downdraft Shaft
6	W10894861	Cover, Spark	12	W10449143	Regulator, Pressure	22	W11249635	Screw
7	W10475150	Module, Spark	13	W11507167	Seal, Switch Shaft	23		Tube, Manifold (Not Serviced)
8	W10361756	Fitting, Gas Supply	14	W11537719	Harness, Switch	24	3400804	Screw, Bracket
9	W11512356	Manifold Assembly	15	W11577790	Screw			
			16	W10827689	Assembly, Tube (Left Front)			

OPTIONAL PARTS NOT INCLUDED

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORY PARTS
W11042467		Spray, Stainless Steel Cleaning
W10620783		Kit, Ductless Downdraft Vent
W10177003		Filter (Ductless)