


**KitchenAid®**

**30" INDUCTION SLIDE-IN RANGE  
(Even-Heat True Convection)**

**MODELS:**

KSIB900ESS2 (Stainless)


# COOKTOP PARTS



# COOKTOP PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>                 | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>            | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>              |
|-------------------|-----------------|------------------------------------|-------------------|-----------------|-------------------------------|-------------------|-----------------|---------------------------------|
| 1                 |                 | Literature Parts                   | 9                 | W10555923       | Bracket, User Interface       | 21                | W10598048       | Bracket, Console (Center)       |
|                   | W10744014       | Installation, Instructions         | 10                | 7101P485-60     | Screw, Anti-Tip Kit           | 22                | W10558372       | Bracket, Control                |
|                   | W10896674       | Use and Care Guide                 | 11                | W10606241       | Bracket, Anti-Tip             | 23                | W10757531       | Keypad, Shield                  |
|                   | W10844271       | Sheet, Tech                        | 12                | W10162253       | Brace, Corner (Left)          | 24                | W10612719       | Gasket, Console/ Cooktop        |
|                   | W10400064       | Guide, Quick Start (English)       |                   | W10162252       | Brace, Corner (Right)         |                   |                 | FOLLOWING PARTS NOT ILLUSTRATED |
|                   | W10400065       | Guide, Quick Start (French)        | 13                | W10289169       | Support, Cooktop (Right)      | W11171883         |                 | Harness, Main                   |
|                   | W10903850       | Wiring Diagram                     |                   | W10289170       | Support, Cooktop (Left)       | W11172426         |                 | Harness, Display                |
| 2                 |                 | Console, Lower Panel               |                   |                 | Vent, Trim Top                | W10575120         |                 | Harness, Keypad                 |
|                   | W10743276       | Stainless                          | 14                |                 | Stainless                     | W11172530         |                 | Harness, Bake Drawer            |
| 3                 | 3196178         | Screw                              |                   | W10636529       | Endcap                        | W10653092         |                 | Suppressor                      |
| 4                 |                 | Cooktop                            | 15                |                 | Stainless (Left)              | 3196520           |                 | Clip, Wire                      |
|                   | W10536317       | Black                              |                   | W10555937       | Stainless (Right)             | 7103P027-60       |                 | Nut                             |
| 5                 | W10636723       | Element (Left Front and Left Rear) | 16                |                 | Console                       |                   |                 |                                 |
|                   |                 |                                    |                   | W10901127       | Stainless                     |                   |                 |                                 |
| 6                 | W10410580       | Hotplate (Right Rear)              | 17                | W10664705       | Bumper                        |                   |                 |                                 |
| 7                 | W10410578       | Element (Right Front)              | 18                | W10759304       | Control, Electronic (Maxwell) |                   |                 |                                 |
| 8                 | W10759323       | Assembly, Display                  | 19                | 3196068         | Lens, Indicator               |                   |                 |                                 |
|                   |                 |                                    | 20                | W10808070       | Interface, User               |                   |                 |                                 |


# INTERIOR PARTS



# INTERIOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>               | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>  |
|-----------------------------|-----------------|----------------------------------|-----------------------------|-----------------|------------------------------|-----------------------------|-----------------|---------------------|
| 1                           | W10854048       | Pan, Induction (Upper)           | 5                           | W10606133       | Duct, Recirculation<br>Plate | 7                           | W10854045       | Spring (Cantilever) |
| 2                           | W10873520       | Assembly, Induction<br>Module    | 6                           | 3196169         | Screw                        | 8                           | W10884792       | Insulation, Shield  |
| 3                           | W10536319       | Pan, Induction (Lower)           |                             |                 |                              |                             |                 |                     |
| 4                           | W10719194       | Assembly, Induction<br>Side Duct |                             |                 |                              |                             |                 |                     |


# CHASSIS PARTS



# CHASSIS PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>          | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>           | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>              |
|-------------------|-----------------|-----------------------------|-------------------|-----------------|------------------------------|-------------------|-----------------|---------------------------------|
| 1                 | W10289077       | Receiver, Hinge             | 21                | W10246624       | Block, Terminal              | 40                | W10346147       | Pan, Bake                       |
| 2                 | W10362924       | Screw                       | 22                |                 | Back, Main (Not Serviced)    | 41                | W10911366       | Rack, Sliding                   |
| 3                 |                 | Panel, Side                 | 23                | 3196178         | Screw                        | 42                | W11117035       | Shield, Wire                    |
|                   | W10162245       | Black                       | 24                | W11175594       | Assembly, Light              | 43                | W10624592       | Cord, Power                     |
| 4                 | 3400029         | Nut                         | 25                | W10571723       | Bulb, Halogen 40 Watts       | 44                | W10162260       | Shield, Heat                    |
| 5                 | W10162385       | Gasket, Door                | 26                | 3400016         | Screw                        | 45                | W10162241       | Channel, Rear                   |
| 6                 | W10544952       | Element, Broil              | 27                | W10586204       | Sensor                       | 46                | W10162248       | Cover, Wire                     |
| 7                 | W10774342       | Element, Bake               | 28                | 3196169         | Screw                        | 47                | W10289172       | Cover, Back                     |
| 8                 | W10362924       | Screw                       | 29                | W10655441       | Shield, Power Cord           | 48                | W10603482       | Rack, Ladder                    |
| 9                 | W11122085       | Assembly, Flue              | 30                | W10346153       | Baffle, Full Convection      | 49                | W10554007       | Rack, Steam                     |
| 10                | W10289168       | Box, Burner SI              | 31                | W10273192       | Rod, Door Switch             | 50                | W10645947       | Grommet                         |
| 11                | W10341186       | Assembly, Front Foot        | 32                | 9758701         | Spacer, Door                 |                   |                 | FOLLOWING PARTS NOT ILLUSTRATED |
| 12                | W10067840       | Screw                       | 33                | W10774446       | Bottom, Oven                 | W10655489         |                 | Insulation, Wrapper             |
| 13                | W10541959       | Shield, Bake                | 34                | W10627802       | Switch, Door                 | W10655490         |                 | Insulation, Main Back           |
| 14                | W10137382       | Clip, Panel                 | 35                | W10281322       | Kit, Bare Wire Adapter Block | W10655442         |                 | Insulation, Heat Shield         |
| 15                | W10390008       | Assembly, Base Rail (Left)  | 36                | W10554006       | Rack, Maximum Capacity       | W10575374         |                 | Insulation, Bottom              |
|                   | W10390007       | Assembly, Base Rail (Right) | 37                | W10874472       | Assembly, Convection         | 4820F015-59       |                 | Insulation, Strap               |
| 16                | W10058460       | Foot, Leveling              | 38                | W10686408       | Kit, Reservoir (Steam Rack)  | 7111P017-60       |                 | Clamp, Wire                     |
| 17                | 3196548         | Fuse, Thermal               | 39                | W10273002       | Bracket, Oven Support        |                   |                 |                                 |
| 18                | 3196172         | Screw                       |                   |                 |                              |                   |                 |                                 |
| 19                | W10035900       | Support, Oven Bottom        |                   |                 |                              |                   |                 |                                 |
| 20                | 3186034         | Bracket, Service            |                   |                 |                              |                   |                 |                                 |

# DOOR PARTS






# DOOR PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>    |
|-------------------|-----------------|-----------------------|
| 1                 | W10813142       | Spacer, Glass         |
| 2                 |                 | Assembly, Door Handle |
|                   | W10551000       | Stainless             |
| 3                 | W10518672       | Badge                 |
| 4                 | W10826568       | Liner, Door           |
| 5                 | W10031790       | Screw                 |
| 6                 | W11223202       | Glass, Inner          |
| 7                 | W10885519       | Hinge, Door (Active)  |

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>          |
|-------------------|-----------------|-----------------------------|
| 8                 | W10541911       | Bracket, Glass Upper Handle |
| 9                 | W10813139       | Rail, Vertical Support      |
| 10                | 9780274         | Screw                       |
| 11                | W10813140       | Rail, Horizontal Support    |
| 12                | W10031780       | Screw                       |
| 13                | W10319024       | Washer, Door                |

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>   |
|-------------------|-----------------|----------------------|
| 14                |                 | Assembly, Outer Door |
|                   | W10634271       | Stainless            |
| 15                |                 | Scoop, Door          |
|                   | W10551024       | Stainless            |

# DRAWER PARTS



# DRAWER PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>    | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>       |
|-----------------------------|-----------------|-----------------------|-----------------------------|-----------------|--------------------|-----------------------------|-----------------|--------------------------|
| 1                           |                 | Handle, Drawer        | 6                           | 3196560         | Screw              | 14                          | 3823F017-45     | Spacer, Handle           |
|                             | W10551000       | Stainless             | 7                           | 3400882         | Screw              | 15                          | W10551018       | Insulation, Drawer Front |
| 2                           | W10757442       | Drawer, Bake          | 8                           | W10634260       | Enclosure, Warming | 16                          | W10550982       | Insulation, Drawer       |
| 3                           | W10550987       | Seal, Drawer          | 9                           | W10727084       | Cover, Gas Valve   | 17                          | W10541947       | Panel, Front Inner       |
| 4                           |                 | Panel, Drawer Front   | 10                          | W10634259       | Cover, Wire        | 18                          | W10729897       | Fuse, Thermal            |
|                             | W10541954       | Stainless             | 11                          | W10720530       | Sensor             | 19                          | 3196560         | Screw                    |
| 5                           | W10921904       | Slide, Drawer (Left)  | 12                          | W10541944       | Element, Bake      | 20                          | W10602493       | Rack, Bake Drawer        |
|                             | W10921905       | Slide, Drawer (Right) | 13                          | W10551019       | Cover, Side        |                             |                 |                          |

# OPTIONAL PARTS (NOT INCLUDED)

## PAINT, TOUCH-UP (1/2OZ.)

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>      |
|-------------------|-----------------|-------------------------|
|                   | 72017           | White                   |
|                   | 72032           | Black                   |
|                   | 4392899         | Biscuit/Bisque          |
|                   | 511873          | White Porcelain (2 oz.) |

## PAINT, PRESSURIZED SPRAY (12 OZ.)

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u> |
|-------------------|-----------------|--------------------|
|                   | 350930          | White              |
|                   | 285006          | Black              |
|                   | 4392901         | Biscuit/Bisque     |

## PAINT, BULK (1 QT.)

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u> |
|-------------------|-----------------|--------------------|
|                   | 799344          | White (Uncut)      |

## REFINISHING MATERIAL

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>        |
|-------------------|-----------------|---------------------------|
|                   | 242756          | Oven Liner Touch Up Paint |

## INSULATION

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>               |
|-------------------|-----------------|----------------------------------|
|                   | 261514          | Insulation (1-1/2" x 24" x 120") |
|                   | 240132          | Insulation (2-1/2" x 22" x 120") |

## ACCESSORY PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>              |
|-------------------|-----------------|---------------------------------|
|                   |                 | CLEANERS / POLISHES             |
|                   | 31605           | Kit, Cooktop Care               |
|                   | 31463A          | Protectant, Cooktop             |
|                   | W10355051       | Cleaner, Cooktop                |
|                   | W10355016       | Cleaner, Stainless Steel        |
|                   | WA906B          | Scraper, Cooktop                |
|                   | W10355049       | Wipes, Stainless Steel Cleaning |
|                   | W10275756       | Cleaner, Granite                |
|                   | 31617A          | Cleaner, Grate & Drip Pan       |
|                   | W10432019       | Alt Cleaning Kit                |
|                   | W10391473       | Pad, Cooktop Cleaning           |
|                   |                 | MISCELLANEOUS                   |
|                   | 4396923         | Grid, Broiler Pan and           |
|                   | W10123240       | Rack, Broiler Pan & Roasting    |
|                   | W10432539       | Griddle                         |
|                   | W10432545       | Kit, Grill                      |
|                   |                 | TRIM KITS                       |
|                   | W10675026       | Black                           |
|                   | W10675027       | White                           |
|                   | W10675028       | Stainless                       |
|                   |                 | BACKSPLASH ASSEMBLY             |
|                   | W10655449       | Black                           |
|                   | W10655448       | White                           |
|                   | W10655450       | Stainless                       |