


**KitchenAid®**

**30" INDUCTION SLIDE-IN RANGE  
(Even-Heat True Convection)**

**MODELS:**

KSIB900ESS3 (Stainless)


# COOKTOP PARTS



# COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	11	W11379947	Bracket, Anti-Tip	21	W10598048	Bracket, Console (Center)
	W11477340	Use and Care Guide	12	W10162253	Brace, Corner (Left)	22	W10558372	Bracket, Control
	W11393919	Tech Sheet		W10162252	Brace, Corner (Right)	23	W11355689	Keypad Shield
	W11477341	Quick Start Guide	13	W10289169	Support, Cooktop (Right)			FOLLOWING PARTS NOT ILLUSTRATED
2		Console, Lower Panel		W10289170	Support, Cooktop (Left)	W11454514		Harness, Main
	W10743276	Stainless			Vent, Trim Top	W11172426		Harness, Display
3	3196178	Screw	14		Stainless	W10575120		Harness, Keypad
4		Cooktop		W10636529	Endcap	W11172530		Harness, Bake Drawer
	W10536317	Black	15		Stainless (Left)	W10653092		Suppressor
5	W10636723	Element (Left Front and Left Rear)		W10555937	Stainless (Right)	3196520		Clip, Wire
				W10555940	Console	7103P027-60		Nut
6	W10410580	Hotplate (Right Rear)	16		Stainless			
				W10901127	Bumper			
7	W10410578	Element (Right Front)	17	W10664705	Control, Electronic (Maxwell)			
			18	W10759304	Gasket, Console/ Cooktop			
8	W10759323	Assembly, Display	19	W10612719	Interface, User			
9	W10555923	Bracket, User Interface	20	W10808070				
10	7101P485-60	Screw, Anti-Tip Kit						


# INTERIOR PARTS



# INTERIOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10854050	Pan, Induction (Upper)	5	W10606133	Duct, Recirculation Plate	7	W10854045	Spring (Cantilever)
2	W10873520	Assembly, Induction Module	6	3196169	Screw	8	W10884792	Insulation, Shield
3	W10536319	Pan, Induction (Lower)						
4	W10719194	Assembly, Induction Side Duct						


# CHASSIS PARTS



# CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	21	W10246624	Block, Terminal	40	W11379357	Bake Pan
2	W10362924	Screw	22	W10645947	Grommet	41	W10911366	Rack, Sliding
3		Panel, Side	23	3196178	Screw	42	W11117035	Shield, Wire
	W10162245	Black	24	W11430367	Light Assembly	43	W10624592	Cord, Power
4	3400029	Nut	25	W10571723	Bulb, Halogen 40 Watts	44	W10162260	Shield, Heat
5	W11491752	Gasket, Door				45	W10162241	Channel, Rear
6	W10544952	Element, Broil	26	3400016	Screw	46	W10162248	Cover, Wire
7	W10774342	Element, Bake	27	W10586204	Sensor	47	W11379354	Cover, Back
8	W10362924	Screw	28	3196169	Screw	48	W10603482	Rack, Ladder
9	W11122085	Assembly, Flue	29	W10655441	Shield, Power Cord	49	W10554007	Rack, Steam
10	W10289168	Box, Burner SI	30	W10346153	Baffle, Full Convection			FOLLOWING PARTS NOT ILLUSTRATED
11	W10341186	Front Foot Assembly	31	W11370463	Rod, Door Switch			
12	W10067840	Screw	32	9758701	Spacer, Door	W10655489		Insulation, Wrapper
13	W10541959	Shield, Bake	33	W10774446	Bottom, Oven	W10655490		Insulation, Main Back
14	W10137382	Clip, Panel	34	W10627802	Switch, Door	W10655442		Insulation, Heat Shield
15	W10390008	Base Rail Assembly (Left)	35	W10281322	Kit, Bare Wire Adapter Block	W10575374		Insulation, Bottom
	W10390007	Base Rail Assembly (Right)	36	W10554006	Rack, Maximum Capacity	4820F015-59		Insulation, Strap
16	W10058460	Foot, Leveling	37	W11353932	Convection Assembly	7111P017-60		Clamp, Wire
17	3196548	Fuse, Thermal	38	W10686408	Kit, Reservoir (Steam Rack)			
18	3196172	Screw	39	W10273002	Bracket, Oven Support			
19	W10035900	Support, Oven Bottom						
20	3186034	Bracket, Service						

# DOOR PARTS






# DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11379948	Glass Spacer
2		Assembly, Door Handle
	W10551000	Stainless
3	W10518672	Badge
4	W10826568	Liner, Door
5	W10031790	Screw
6	W11223202	Glass, Inner
7	W10885519	Hinge, Door (Active)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10541911	Bracket, Glass Upper Handle
9	W10813139	Rail, Vertical Support
10	9780274	Screw
11	W10813140	Rail, Horizontal Support
12	W10031780	Screw
13	W10319024	Washer, Door

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
14		Assembly, Outer Door
	W10634271	Stainless
15		Scoop, Door
	W10551024	Stainless
16	W10766562	Insulation, Door

# DRAWER PARTS



# DRAWER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle, Drawer	6	3196560	Screw	15	W10551018	Insulation, Drawer Front
	W10551000	Stainless	7	3400882	Screw	16	W10550982	Insulation, Drawer
2	W10757442	Drawer,Bake	8	W10634260	Enclosure, Warming	17	W10541947	Panel, Front Inner
3	W10550987	Seal, Drawer	9	W10727084	Cover, Gas Valve	18	W10729897	Fuse, Thermal
4		Panel, Drawer Front	10	W10634259	Cover, Wire	19	3196560	Screw
	W10541954	Stainless	11	W10720530	Sensor	20	W10602493	Rack, Bake Drawer
5	W10921904	Slide, Drawer (Left)	12	W10541944	Element, Bake	21	W10551011	Insulation, Bake Drawer Bottom
	W10921905	Slide, Drawer (Right)	13	W10551019	Cover, Side			
			14	3823F017-45	Spacer, Handle			

# OPTIONAL PARTS (NOT INCLUDED)

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	511873	White Porcelain (2 oz.)

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

## REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

## INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

## ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		CLEANERS / POLISHES
	31605	Kit, Cooktop Care
	31463A	Protectant, Cooktop
	W10355051	Cleaner, Cooktop
	W10355016	Cleaner, Stainless Steel
	WA906B	Scraper, Cooktop
	W10355049	Wipes, Stainless Steel Cleaning
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	W10432019	Alt Cleaning Kit
	W10391473	Pad, Cooktop Cleaning
		MISCELLANEOUS
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting
	W10432539	Griddle
	W10432545	Kit, Grill
		TRIM KITS
	W10675026	Black
	W10675027	White
	W10675028	Stainless
		BACKSPLASH ASSEMBLY
	W10655449	Black
	W10655448	White
	W10655450	Stainless