

REPLACEMENT PARTS LIST

(SUB-123)

Reference #	Description	Replacement Part #
ELECTRICAL COMPONENTS - -		
1	Power Terminal Block	50-0237
2	Ground Lug	50-0062
3	Contactor:	
	120-volt coil, 40-amp (US)	66-2013
4	Oven Temperature Control Circuit Board 425 degree F	252-5008
5	Oven Temperature Control Sensor	252-3001
6	Oven Heating Element:	
	208-volt, 2000-watt	251-1005
	240-volt, 2000-watt	251-1002
7	Oven Motor Assy. 120 V	250-1002
8	Proofer Temperature Control Circuit Board	252-4001
9	Proofer Temperature Control Sensor	252-3001
10	Proofer Humidity Control Circuit Board	252-4001
11	Proofer Humidity Control Sensor	252-3001
12	Proofer Heat Element, 120-volt, 255-watt(Manual Fill)	60-0002-1
13	Proofer Humidity Element Assembly(Manual Fill):	
	120-volt, 650-watt (US)	251-2001
14	Proofer Motor and Fan Assembly:	
	120v 60 Hz (US)(Manual Fill)	250-2004
15	Door Micro Switch	252-2004
16	Buzzer Alarm:	
	60 Hz (US)	252-1003
17	Thermal Overload Safety (425°F)	252-1021
18	Cooling Fan:	
	120v (US)	250-3001
19	Light Fixture:	
	Socket	50-1020
	Bulb 130v 40w Brass Based Appliance Bulb.....	50-0695
	Light fixture kit Oven (Socket, Globe, and Gasket)	252-7004
	Light Cover Globe only.....	50-1021
	Oven Light Cover Gasket only	70-0354-A
	Light fixture kit Proofer (Socket, Globe, and Gasket)	252-7006
	Light Cover Globe only.....	50-1021
	Proofer Light Cover Gasket only.....	70-0361-A

OVEN CONTROL COMPONENTS --

21	Oven Power Switch (Lighted rocker style)	50-1355
	Oven Power Switch (Black breaker style)	252-6001
22	Temperature Control, 425°F	252-5008
	Control Knob	253-2003
23	Temperature Control Indicator Light:	
	120-volt (US)	50-0029-A
24	Oven Timer:	
	60-Minute Mechanical	252-1004
	Timer Knob	253-2002
	99-Minute Digital (optional)	66-8133
25	Thermometer, 450° (optional)	50-1309

PROOFER CONTROL COMPONENTS --

31	Proofer Power Switch (Lighted rocker style).....	50-1355
	Power Switch (Black breaker style)	252-6001
32	Temperature Control	252-4001
	Control Knob	253-2003
33	Temperature Control Indicator Light:	
	120-volt (US)	50-0029-A
34	Humidity Control	252-4001
	Control Knob	253-2003
35	Humidity Control Indicator Light:	
	120-volt (US)	50-0029-A
36	Proofer Timer:	
	60-Minute Mechanical	252-1004
	Timer Knob	253-2002
	99-Minute Digital (optional).....	66-8133

DOOR COMPONENTS --

41	Oven Door (without hardware):	
	Hinged Left	112-9033
	Hinged Right	112-9032
42	Proofer Door (without hardware):	
	Hinged Left	21-1950
	Hinged Right	21-1950
43	Door Hinge:	
	Left side	254-3011
	Right side	254-3012
	PTFE Door Lift	21-1028-A
44	Latch/Catch Assembly	254-2007
46	Gasket:	
	Oven Door	254-1012
	Proofer Door	70-0358-A

PROOFER INTERIOR COMPONENTS - - (Manual fill proofer only)

64	Water Pan	50-0074
65	Shelf	112-0059-B

GENERAL EXTERIOR COMPONENTS - -

75	Caster	50-0058
77	Drain Pan	50-0547

AUTOMIST COMPONENTS - -

81	Humidity Control	252-3003
	Control Knob	253-2003
82	Humidity Control Indicator Light:	
	120-volt (US)	50-0029-A
	240-volt (non-US)	50-0030
83	Repeat Cycle Timer:	
	120-volt (US)	66-8012
	240-volt (non-US)	66-8065
84	Water Solenoid Valve:	
	120-volt (US)	50-0308-1
	240-volt (non-US)	50-0307-1
85	Humidity Injection Nozzle	31-0033
86	Automist Proofer Motor and Fan Assy.	250-2010
87	Heat Element, 120-volt 600-watt	60-0001-1-B
