

**WDC1025 & LWD1054
CABINET**

NO.	PART NUMBER	DESCRIPTION
1	111100830	Top Panel
2	112903512	Top Deco Element
3	116102880	Module Assembly, Electronic
4	116990422	Block, Junction
5	112902490	Support, Drain Hose
6	119100642	Cabinet
7	111100884	Panel, Back
8	113800472	Spring, Tub Suspension
9	116102798	Switch, Pressure
10	113200152	Clamp, Hose To Pressure Switch
11	113800437	Shock Absorber, Right {Long}
12	114300725	Hose, Drain
13	116590746	Pump
14	113200240	Clamp, Drain Hose To Pump
15	113200087	Clamp, Drain Filter Hose To Pump
16	119803162	Hose, Pressure Switch To Drain Filter
17	113200354	Clamp, Pressure Switch Hose To Drain Filter Assembly
18	114300737	Hose, Filter To Pump
20	112990007	Drain Filter Assembly {Before 9719}
20A	112990007A	Drain Filter Assembly {9719 to 9840}
21	114200666	Gasket, Drain Filter
22	113800431	Spring, Drain Filter Door
23	113900489	Pin, Drain Filter Door
24	111100676	Door, Drain Filter
25	119803003	Screw, Leveling
26	116102994	Switch, Door Interlock
28	182990046	Plate, Hook Stop
29	113200491	Clamp, Drain Filter Hose To Drain Filter Assembly
30	112990035	Door Flange
31	112100570	Door Ring
32	112300234	Retainer, Door Hook
33	112903262	Strap, Drain Hose Attachment
34	113190122	Hinge Assembly
35	112903334	Glass, Safety
36	112901939	Hook, Adhesive
39	112400459	Housing, Module
40	113800459	Spring, Door Hook

42	112300233	Hook, Door
43	113900056	Pin, Door Hook
45	111901158	Support, Pressure Switch
46	113800436	Shock Absorber, Left {Short}
47	112902017	Plug, Spring Attachment
49	114400211	Pad, Rubber
52	956333616	Rivet, Front Plate
53	112903121	Wiring Support
54	111901172	Plate, Front Mounting
55	112903365	Cord, Door Interlock
56	111901116	Plate, Hook Spring Mount
57A	112903475A	Door Opening Assembly, Push Button

