



# FFSEL6069-24

No.	Material Name	Material Code	Qty.
1	Side plate	G20C01-071003	2
2	Cavity right plate	G20A01-070501-92	1
3	Anti-tip bracket	G20A01-212500	2
4	Weight block	E20F05-210200	1
5	Foot F01	E20F01-071500	2
6	Leg installation plate	G20A01-071100	2
7	Front plate Beam	G24R10-070200-92	1
9	Cavity left plate	G20A01-070401-92	1
10	Front plate	G24C01-070102-92	1
11	Drawer rail	G20A01-120700	2
12	Drawer plate	G24C03-120500-02	1
13	Drawer inside plate	G24R10-120200-04	1
14	Drawer outside plate	G24R10-120100	1
15	DOOR handle	G24R08-101900	2
16	door seal	G24C01-071200	1
17	Door outside stainless steel frame	G24R10-100400	1
17	L shape fixed part for door outer glass	G36R03-101200	4
17	Straight fixed part for door outer glass	G36R03-101300	2
18	Door outer glass fix part	G24R10-101700-02	2
19	Door outer glass	G24R10-101100	1
20	Door insulation board	G24R10-101400	1
21	Door glass wool	G24R10-103500	1
22	Door inner glass top and down body frame	G24R10-101500	2
23	Door inner glass left and right body frame	G24R10-101600	2
24	Door inside glass	G24R10-100500	2
25	Door hinge	G20G02-110002	2
26	Door component assembly	G24R10-100600-92Z	1
27	Foot	G20C01-071500	2
29	Knob for top burners	E20R08-030100	4
29	Knob for thermostat	E20R08-030101	1
30	Knob ring	G36R03-030200	5
31	Control panel	E24R10-030300	1
32	indicate light-red	E24F08-031001	3
33	switch button	E24H08-170200	1
34	Fan cover	G20H08-091700-92	1

36	Round press button	G36X07-170200	3
37	Digital thermo-controller	E24R10-030900	1
38	cooktop coil switch	E24F01-031600	4
39	Roast motor	G20A01-200101	1
40	Strip bar for control panel	E24F08-214500	1
41	Spring for radition plate	E24F08-026100	8
42	bolt for radition plate	E24R10-025100	8
43	Cooktop ceramic glass	E24R10-030200	1
44	Convection fan motor	G20A01-091501	1
45	cooktop plate	E24R10-020100	1
46	Backsplash assembly	G24R10-011500-Z	1
47	Rear connecting plate	G20C01-022000	2
48	Cavity top plate	G24C01-070604-92	1
50	boril heater element	E24F01-091000	1
52	Cooling fan	E24F08-200900	1
53	Oven lamp	G20C01-180101	1
54	Back plate	G24C01-070307-92	1
56	Baffle plate	E24F01-072000	1
57	terminal block cover	E24F08-072000	1
59	Deep tray	G24E05-070700-92	1
61	snap action temperature controller R05	C36R05-076200	1
62	Air fry basket	E24R10-073800	1
63	Rack	G24H08-071900	2
64	oven heater element	E24F01-091200	1
65	terminal block support	E24F01-034500	1
66	Cavity bottom plate	E24F08-070700-92	1
69	snap action temperature controller F01	E24F01-076200	1
70	main terminal block	E20F01-106400	1
71	Roast fork assembly	G20A01-200601	2
71	Roast axis	G24A01-200501	1
73	Left support for radition plate	E24R10-024100	1
73	Right support for radition plate	E24R10-024200	1
75	Radition plate 1800W	E20R08-022400	2
76	Radition plate 1200W	E20R08-022300	2