





# RPC - 14 PASTA COOKER



## RPC-14 - PASTA COOKER - PART LIST

ITEM NO.	PART NO.	DESCRIPTION
1	1671	PILOT ASSY - NATURAL
	1672	PILOT ASSY - L.P.
2	33083	VESSEL WLDMT
3	41675	BOTTOM SCREEN
4	3710	BULK PASTA BASKET
5	28221	BACK PANEL TOP
6	2192	PLATE CASTER WITHOUT BRAKE
	2193	PLATE CASTER W-BRAKE
7	1219	CONE LEG
8	3717	ELBOW, BRASS0
9	3718	ADAPTER, BRASS
10	3149	DRAIN VALVE
11	3201-42	ORIFICE BURNER -NATURAL
	3202-54	ORIFICE BURNER - L.P.
12	3138	BURNER
13	2605	THERMOSTAT
14	2606	KNOB, THERMOSTAT
15	3933	MANIFOLD PIPE
16	3711	WATER VALVE
17	28443	WATER SUPPLY TUBE WLDMT
18	3114	GAS VALVE NATURAL
	3115	GAS VALVE L.P.
19	3716	ELBOW, BRASS
20	3721	ADAPTER, BRASS
21	3732	INLET TUBE FORMED, WATER VALVE TO SPOUT
22	28237	DOOR ASSY
23	3713	SILICONE HOSE
24	33066	CONTROL PANEL
25	3733	OUTLET TUBE FORMED, VALVE TO SST TUBE
26	28674	TRAY, OVERFLOW
27	3709	ROUND PASTA BASKET
28	2653	ROYAL LOGO, LARGE, OVAL